



without Built-In Releasing Control Panel

INSTALLATION, OPERATION, AND MAINTENANCE MANUAL

Serial Number _____

Date of Installation _____ **Date of Commissioning** _____



UNITED Fire Systems

1 Mark Road
Kenilworth, NJ USA 07033
908-688-0300

www.unitedfiresystems.com

Manual Part Number 10-500003-00N

**Version 1.0
October 2020**

INDEX

| Section | Description | Page |
|---------|---|------|
| | Index | i |
| | List of Figures | ii |
| | List Of Tables | ii |
| | Hazard Identification | iii |
| | Foreword | iv |
| | Warranty | v |
| 1 | General | |
| 1.1 | Introduction | 2 |
| 1.2 | Features | 2 |
| 1.3 | Functional Description | 6 |
| 1.4 | Configurations | 8 |
| 1.5 | Options | 8 |
| 1.6 | Approvals | 8 |
| 1.7 | Applicable Standards | 8 |
| 1.8 | Applicable Manuals | 8 |
| 1.9 | FM Approved Assemblies | 9 |
| 1.10 | Installation | |
| 1.10.1 | Location | 11 |
| 1.10.2 | Unpacking, Placement, and Leveling | 11 |
| 1.10.3 | Serial Number | 13 |
| 1.10.4 | External Attachments | 13 |
| 1.10.5 | Prior To Placing In Service | 21 |
| 1.10.6 | Placing In Service | 21 |
| 1.11 | Operation | |
| 1.11.1 | Automatic | 21 |
| 1.11.2 | Manual | 21 |
| 1.11.3 | Restoring To Service | 22 |
| 1.12 | Inspection, Testing, and Maintenance | 22 |
| 2 | Tyco Manual TFP1461 – Tyco DV-5A Automatic Water Control Valve, Double Interlock, Preaction, Electric/Pneumatic Actuation | |
| 3 | General Air Products Manual OILLESSINST – Compressor | |
| 4 | United Fire Systems UFS-710 – NAMD-1 Nitrogen/Air Maintenance Device | |

LIST OF FIGURES

| Figure No. | Description | Page |
|------------|--|------|
| 1 | Illustration - PREACTION-PAC™ Shown With Enclosure Doors Closed | 1 |
| 2 | Illustration - PREACTION-PAC™ Shown With Enclosure Doors Open | 3 |
| 3a | Diagram - Functional Description (Compressor) | 4 |
| 3b | Diagram - Functional Description (Pressure Maintenance Device) | 5 |
| 4 | Diagram – Overall Dimensions | 11 |
| 5 | Diagram - Location of Pallet Bolts and Leveling Feet | 12 |
| 6 | Diagram - Piping Attachment Details | 14 |
| 7a | Diagram - Terminal Strip Wiring Detail (Compressor) | 16 |
| 7b | Diagram - Terminal Strip Wiring Detail (Pressure Maintenance Device) | 18 |

LIST OF TABLES

| Table No. | Description | Page |
|-----------|---|------|
| 1.9 | FM Approved Assemblies with No Built-In Releasing Control Panel | 10 |

HAZARD IDENTIFICATION

Carefully read, understand, and follow instructions identified by these symbols.



The use of the word “DANGER” identifies an immediate hazard with a likelihood of death or serious personal injury if instructions, including recommended precautions, are not followed.



The use of the word “WARNING” identifies the presence of hazards or unsafe practices that could result in death, personal injury, or serious property damage if instructions, including recommended precautions, are not followed.



The use of the word “CAUTION” identifies possible hazards or unsafe practices that could result in personal injury or property damage if instructions, including recommended precautions, are not followed.



The use of the word “IMPORTANT” identifies special instructions, not related to hazards, that should be followed.

FOREWORD

This manual is written for those who install, operate and maintain **UNITED Fire Systems PREACTION-PAC™** sprinkler valve assemblies. The manual contains installation, operation, and maintenance information for these assemblies.



IMPORTANT

UNITED Fire Systems assumes no responsibility for the installation, operation, or maintenance of any systems other than those addressed in this manual. The data contained in this manual is for information purposes only. **UNITED Fire Systems** believes this data to be accurate at the time of publication, but the data is published and presented without any guarantee or warranty whatsoever. **UNITED Fire Systems** disclaims any liability for any use that may be made of the data and information contained in this manual by any and all parties.



IMPORTANT

The **UNITED Fire Systems PREACTION-PAC™** sprinkler valve assembly is a vital part of the fire protection of any facility where these units are installed. Life safety and property protection depends on continuing proper operation of the assembly. The owner of the **PREACTION-PAC™** is responsible for the condition of the assembly and its continued proper operation. **UNITED Fire Systems** strongly recommends that all owners of **PREACTION-PAC™** engage the services of qualified, trained fire protection professionals to design the system containing the assembly, and to install and maintain the assembly.

UNITED Fire Systems PREACTION-PAC™ sprinkler valve assemblies are to be installed and maintained by qualified, trained personnel in accordance with:

- This Installation, Operation, and Maintenance Manual P/N 10-500003-00N.
- National Fire Protection Association No. 13, “Standard for the Installation of Sprinkler Systems.”
- National Fire Protection Association No. 25, “Standard for the Inspection, Testing, and Maintenance of Water-Based Fire Protection Systems.”
- National Fire Protection Association No. 70, “National Electrical Code®”.
- National Fire Protection Association No. 72, “National Fire Alarm Code®”.

Any questions on the information in this manual should be addressed to:

UNITED Fire Systems
1 Mark Road
Kenilworth, NJ USA 07033
908-688-0300
www.unitedfiresystems.com



LIMITED WARRANTY PREACTION-PAC™



What Does This Warranty Cover?

This Limited Warranty covers all manufacturing defects in material and workmanship in all equipment supplied by **UNITED Fire Systems** for new **PREACTION-PAC™** sprinkler valve assemblies.

How Long Does The Coverage Last?

This Limited Warranty lasts for either eighteen (18) months from the date of shipment to the original purchaser or twelve (12) months from the date of commissioning by **UNITED Fire Systems** or a trained distributor, whichever comes first.

What Will **UNITED Fire Systems** Do?

UNITED Fire Systems will repair, replace, or refund the purchase price of, at its option, any defective **PREACTION-PAC™** equipment at no charge.

What Does This Warranty Not Cover?

- Equipment that is not supplied by **UNITED Fire Systems** is not covered.
- Equipment that has not been installed, commissioned, operated, and maintained per the instructions in the applicable **UNITED Fire Systems** instruction manual is not covered.
- Equipment that has been repaired, modified, or otherwise tampered with not in accordance with the applicable **UNITED Fire Systems** instruction manual is not covered.
- Any problem that is caused by abuse, misuse, or an act of God (such as a flood) is not covered.
- Transportation and shipping charges to return equipment to **UNITED Fire Systems** or for **UNITED Fire Systems** to return repaired or replacement equipment are not covered.
- Consequential and incidental damages are not covered. Some states do not allow the exclusion or limitation of incidental or consequential damages, so this exclusion may not apply.

What Are The Customer's Responsibilities?

- Ensuring that the **UNITED Fire Systems** equipment is installed, commissioned, operated, and maintained per the instructions in the applicable **UNITED Fire Systems** instruction manual.
- Where applicable, ensuring that checklists supplied by **UNITED Fire Systems** are properly used and completed at the time of installation, commissioning, operation, and maintenance, and such checklists are retained as records of proper completion.
- Noting and recording the serial number(s) of **UNITED Fire Systems** equipment.
- Notifying **UNITED Fire Systems** or a trained distributor of the need for service under this Limited Warranty.

How Is Warranty Service Obtained?

If anything goes wrong with **UNITED Fire Systems** equipment, contact:

UNITED Fire Systems
Division of United Fire Protection Corporation
1 Mark Road
Kenilworth, NJ 07033 USA
Phone: 908-688-0300
Fax: 908-481-1131
www.unitedfiresystems.com

= OR =

Your
Trained
Distributor

Be prepared to supply the serial number(s) of the equipment requiring service, and copies of the installation, commissioning, and maintenance checklists, as applicable.



LIMITED WARRANTY PREACTION-PAC™



Is This Limited Warranty Transferable?

If the **PREACTION-PAC™** equipment is moved from one to another installation during the time period of Limited Warranty coverage, the **PREACTION-PAC™** equipment must be re-commissioned by **UNITED Fire Systems** or a trained distributor to be eligible for continuing coverage. There will be a quoted charge for this re-commissioning.

Is This The Entire Warranty?

This Limited Warranty is the entire warranty given by **UNITED Fire Systems** to the purchaser of new **PREACTION-PAC™** equipment. Component warranties supplied by component manufacturers to **UNITED Fire Systems** that are valid for a longer period of time than the **UNITED Fire Systems** Limited Warranty may apply. Contact **UNITED Fire Systems** for more information. There are no other warranties expressed or implied, beyond those required by law.

How Do State and Federal Laws Apply?

This Limited Warranty grants specific legal rights per Federal law. There may also be other rights which vary from state to state.

UFS-113 Rev. 2.01 Nov 2020

PREACTION-PAC™
with NO BUILT-IN RELEASING CONTROL PANEL
INSTALLATION, OPERATION, AND MAINTENANCE MANUAL
P/N 10-500003-00N
VERSION 1.00 – NOVEMBER 2020



**Figure 1 –
PREACTION-
PAC™ Shown
With Enclosure
Doors Closed**

1. GENERAL

1.1. Introduction. The **UNITED Fire Systems PREACTION-PAC™** is a fully assembled and factory tested preaction fire suppression system, including preaction valve, and trim, providing one complete zone of preaction water sprinkler fire protection. All components are contained in two steel enclosures assembled one above the other. The system pressure gauges and the required manual release handle are mounted on the front of the lower enclosure. The system electrical connection terminal strip, compressor disconnect switch (where applicable), and spare sprinkler head storage are behind a door in the upper enclosure. Lockable latches on both doors permit authorized access to all system components. Both enclosures are finished in powder-coat red paint. Gasketing provides sealing of the enclosure doors. Knockouts permit easy attachment of external electrical conduits.

1.1.1. Preaction Valve. The preaction valve installed in the **PREACTION-PAC™** is a low-differential, latched clapper valve that uses a unique direct-acting diaphragm to separate the system water supply from the system piping. The positive latching system uses the supply water pressure to hold the clapper shut. When the water pressure in the diaphragm chamber is released, the latch retracts from the clapper and the valve actuates. The low differential and unique latch and actuator design of the valve allows the valve to be self-resetting.

1.1.2. Piping. Water inlet pipe connections are located on the lower left and lower right sides of the lower enclosure. The unused inlet is left plugged. Grooved pipe is used for the inlet connection. The water outlet pipe connection is located at the top center of the lower enclosure, behind the upper enclosure. The drain connection is accessible within the lower enclosure, and knockouts are provided allowing exit of the drain from either side. All pipe connections are done in the lower enclosure.

1.1.3. Wiring. All wiring from the integral terminal strip to the valve solenoid and all switches is factory installed and tested. Where applicable, wiring for compressor power and control is also factory installed and tested. All field wiring for compressor power, switch contacts, and the preaction valve solenoid is connected to a terminal strip in the upper enclosure. No access to the lower enclosure is necessary to complete the wiring installation.

1.1.4. Compressor. For assemblies equipped with a compressor for air pressurization of the preaction sprinkler piping, all wiring and adjustments are performed at the factory. Three sizes of compressor are available, depending on the volume of installed piping to be pressurized. The compressor is mounted using molded rubber mounts and bushings to minimize noise and vibration during motor operation. A compressor disconnect switch is located in the upper enclosure.

1.1.5. Pressure Maintenance Device. Assemblies are equipped with a pressure maintenance device when the source of the supervisory gas is external of the **PREACTION-PAC™**, such as a tank-mounted air compressor or a nitrogen generator. A blank plate replaces the compressor disconnect switch.

1.2. Features

1.2.1. Attractive and rugged metal enclosure. The entire enclosure is manufactured from steel with continuous welded seams. The lower enclosure is 12 gauge, while the upper enclosure is 14 gauge. Both enclosures are coated with red powder-coat paint inside and out. Continuous piano-style hinges attach the doors to the enclosures.


1.2.2. Easy-to-see gauges on front of enclosure. Three pressure gauges are mounted on the front of the lower enclosure, and are visible at all times. These gauges monitor the air pressure in the system piping, the water supply pressure up to the preaction valve, and the water pressure keeping the valve clapper piston closed.

1.2.3. Easy access to manual release valve. The emergency manual release ball valve is located behind a small unlocked door on the front of the lower enclosure. Operation of this ball valve opens the preaction valve, filling the system piping with water. No power is necessary to accomplish this


PREACTION-PAC™
with NO BUILT-IN RELEASING CONTROL PANEL
INSTALLATION, OPERATION, AND MAINTENANCE MANUAL
P/N 10-500003-00N
VERSION 1.00 – NOVEMBER 2020

operation. The key for the lower enclosure main door does not have to be available to accomplish this operation.

- 1.2.4.**Water inlet connections. The water inlet piping may attach to the lower enclosure near the bottom on either side.
- 1.2.5.**Space for required spare sprinkler heads and wrench. As required by NFPA 13, a built-in storage location for spare sprinkler heads and a sprinkler wrench is behind the door of the upper enclosure.
- 1.2.6.**Separate mechanical and electrical enclosures. This allows mechanical and electrical trades to keep their work areas separate.



with NO BUILT-IN RELEASING CONTROL PANEL
INSTALLATION, OPERATION, AND MAINTENANCE MANUAL
P/N 10-500003-00N
VERSION 1.00 – NOVEMBER 2020



Functional Description with Compressor

PREACTION-PAC™
with NO BUILT-IN RELEASING CONTROL PANEL
INSTALLATION, OPERATION, AND MAINTENANCE MANUAL
P/N 10-500003-00N
VERSION 1.00 – NOVEMBER 2020




Figure 3b – Diagram –
Functional Description with Pressure Maintenance Device

1.3. Functional Description. Refer to Figure 3a on page 4 and Figure 3b on page 5.

- 1.3.1. Terminal strip (2).** The terminal strip provides a convenient point for landing the required field wiring.
- 1.3.2. Preaction valve (3).** The preaction valve is the heart of the assembly. The valve holds back the sprinkler water until the field-installed control panel reacts to the signal from the fire detectors and sends a signal to the valve actuation solenoid (4). In single-interlock assemblies, actuation of the valve actuation solenoid (4) sends water into the sprinkler pipe. In double-interlock assemblies, fusing of a sprinkler head from heat is required, along with valve actuation solenoid (4) actuation, to send water into the sprinkler pipe. Refer to Tyco Manual TFP1461 in Section 2 for more detailed information on the preaction valve.
- 1.3.3. Valve actuation solenoid (4).** The valve actuation solenoid receives the signal from the field-installed control panel, and actuates the preaction valve (3). The solenoid is the Victaulic Series 753-E, and is rated at 24VDC, 0.364 amps, 8.7 watts, 66 ohms. The solenoid is FM Approved under Group I (as in India). Refer to Tyco Manual TFP1461 in Section 2 for more detailed information.
- 1.3.4. Waterflow signal switch (5).** The waterflow signal switch responds to waterflow in the pipe downstream of the preaction valve (3). The switch contains Quantity 2, SPDT switches, rated at 10A-125/250VAC, 1/2HP, 2.5A-6/12/24VDC. Contacts transfer when waterflow begins after preaction valve opens. Contacts automatically restore when waterflow ceases. The switch sends a signal to the field-installed control panel.
- 1.3.5. Manual shutoff valve (6).** The manual shutoff valve is used to shut off the flow of water after actuation of the preaction valve (3). The normal position of this valve when the system is in service is open. Refer to Tyco Manual TFP1461 in Section 2 for more detailed information on the use of this valve.
- 1.3.6. Shutoff valve tamper signal switch (7).** The shutoff valve tamper signal switch sends a supervisory signal to the field-installed control panel when the manual shutoff valve (6) is closed. The switch contains Quantity 2, SPDT switches, rated at 10A-125/250VAC, 0.5A-125VDC. Contacts transfer when valve begins to close. Contacts restore when valve is fully open.
- 1.3.7. Compressor (8).** The compressor supplies supervisory air pressure to fill the sprinkler pipe downstream of the preaction valve (3). The sprinkler pipe is pressurized to 13 PSIG minimum and 18 PSIG maximum by the compressor (8). Loss of this pressure, from damage to the pipe or a sprinkler head, results in a supervisory signal at the field-installed control panel.
- 1.3.8. Pressure Maintenance Device (8).** The pressure maintenance device supplies supervisory gas pressure, from either a tank-mounted air compressor or nitrogen generator, to fill the sprinkler pipe downstream of the preaction valve (3). The sprinkler pipe is pressurized to 15 PSIG by the pressure maintenance device (8). Loss of this pressure, from damage to the pipe or a sprinkler head, results in a supervisory signal at the field-installed control panel.
- 1.3.9. High / low air pressure limit switch (9).** The high / low air pressure limit switch is built in to the compressor (8). When pressure in the pipe falls below 13 PSIG, the switch turns the compressor (8) on. When pressure in the pipe rises to 18 PSIG, the switch turns the compressor (8) off.
- 1.3.10. Low pressure signal switch (10).** The low pressure signal switch sends the supervisory signal for low pressure to the field-installed control panel. The switch contains Quantity 2, SPDT switches, rated at 10A-125/250VAC, 1/2HP, 2.5A-6/12/24VDC. Contacts transfer when pressure in the piping falls below 13PSIG. Contacts automatically restore when pressure rises above 13PSIG.
- 1.3.11. Compressor disconnect switch (11).** Where applicable, the compressor disconnect switch is used to manually interrupt the 110VAC power to the compressor motor, during inspection, maintenance, and resetting of the assembly. Only trained personnel should use this switch. The normal position of this switch when the system is in service is ON.
- 1.3.12. Manual station valve (12).** The manual station valve is located behind a separate door on the front of the lower enclosure. No key is needed to open this door. To manually open the preaction

valve (3), open the door and pull the lever on the manual station valve forward. The preaction valve (3) will open, and the sprinkler pipe will fill with water. No power is needed to manually open the preaction valve (3) in this manner.



IMPORTANT

Fusing of a sprinkler head by heat is necessary for water to be discharged onto a fire, even after operation of the manual station valve.

- 1.3.13. Drain valve (13).** The drain valve is used to drain the sprinkler pipe after actuation of the preaction valve (3). This valve is used only during inspection, maintenance, and resetting of the assembly. Only trained personnel should use this valve. Refer to Tyco Manual TFP1461 in Section 2 for more detailed information on this valve. The normal position of this valve is closed.
- 1.3.14. Input connection for 110 VAC power (14).** 110VAC is required to power the assembly. This power shall come from a source in compliance with all applicable codes and standards. Internal wiring (factory assembled) takes this power to the compressor (8). Refer to Section 1.10 for additional information on this connection.
- 1.3.15. Water inlet connection (16).** The sprinkler water supply is field-connected to this connection. One of two optional water inlet connections may be chosen. The connection may be made on the lower right of the assembly, or by removing the cap, the connection may be made on the lower left of the assembly. Refer to Section 1.10 and Section 2 – Tyco Manual TFP1461 for more detailed information on this connection.
- 1.3.16. Outlet connection to fire sprinklers (17).** The outlet connection from the assembly to the fire sprinklers is field-connected to this connection. The connection is located in the top center of the lower enclosure, behind the upper enclosure. Refer to Section 1.10 and Section 2 – Tyco Manual TFP1461 for more detailed information on this connection.
- 1.3.17. Drain connection (20).** Drain water from the assembly must be piped away to a drain. The drain piping may be connected to the assembly on the left or the right side. Refer to Section 1.10 and Section 2 – Tyco Manual TFP1461 for more detailed information on this connection.
- 1.3.18. Output connections to field-installed control panel.** These connections are:
- 1.3.18.1. Valve actuation solenoid (4).** The solenoid is to be connected to the releasing output of an FM Approved releasing control panel. The solenoid is the Victaulic Series 753-E, and is rated at 24VDC, 0.364 amps, 8.7 watts, 66 ohms. The solenoid is FM Approved under Group E.
- 1.3.18.2. Waterflow signal switch (5).** Quantity 2, SPDT switches, rated at 10A-125/250VAC, 1/2HP, 2.5A-6/12/24VDC. Contacts transfer when water flow begins after preaction valve opens. Contacts automatically restore when waterflow ceases. One contact should be connected to signal field-installed control panel, which should respond with ALARM signal.
- 1.3.18.3. Shutoff valve tamper signal switch (7).** Quantity 2, SPDT switches, rated at 10A-125/250VAC, 0.5A-125VDC. Contacts transfer when manual shutoff valve is closed. Contacts automatically restore when shutoff valve is manually re-opened. One contact should be connected to signal field-installed control panel, which should respond with SUPERVISORY signal.
- 1.3.18.4. Low pressure signal switch (10).** Quantity 2, SPDT switches, rated at 10A-125/250VAC, 1/2HP, 2.5A-6/12/24VDC. Contacts transfer when pressure less than 13 PSIG is sensed in the sprinkler pipe. Contacts automatically restore when compressor restores pressure above 13 PSIG. One contact should be connected to signal field-installed control panel, which should respond with SUPERVISORY signal.

PREACTION-PAC™
with NO BUILT-IN RELEASING CONTROL PANEL
INSTALLATION, OPERATION, AND MAINTENANCE MANUAL
P/N 10-500003-00N
VERSION 1.00 – NOVEMBER 2020

1.4. Configurations. **UNITED Fire Systems PREACTION-PAC™** sprinkler valve assemblies are available in the following configurations:

1.4.1. Valve sizes: 2" through 4".

1.4.2. Valve types: Single-interlock and double-interlock available in all valve sizes.

1.4.3. Supervisory gas sources:

1.4.3.1. For 2" valves: 1/6HP compressor and pressure maintenance device available.

1.4.3.2. For 3" and 4" valves: 1/6HP, 1/3HP, and 1/2HP compressors and pressure maintenance device available.

1.4.3.3. Gas sources are capable of pressurizing piping systems up to the following limits:

1.4.3.3.1. 1/6HP compressor: maximum system capacity is 290 gallons.

1.4.3.3.2. 1/3HP compressor: maximum system capacity is 475 gallons.

1.4.3.3.3. 1/2HP compressor: maximum system capacity is 780 gallons.

1.4.3.3.4. Pressure maintenance device: Refer to manual of the external source.

1.5. Options - None at this time.

1.6. Approvals. **UNITED Fire Systems PREACTION-PAC™** sprinkler valve assemblies, as listed in this Manual, are Approved by FM Approvals under the heading "Automatic Water Control Valves." See pages 11 and 12 for Approved assemblies. NOTE: Although most **PREACTION-PAC™** assemblies are FM Approved, custom-built units are supplied from time to time upon request. Various components within these custom assemblies maintain their individual approvals, but these custom assemblies are not FM Approved as a unit.

1.7. Applicable Standards. **UNITED Fire Systems PREACTION-PAC™** sprinkler valve assemblies are to be installed and maintained by qualified, trained personnel in accordance with:

1.7.1. National Fire Protection Association No. 13, "Standard for the Installation of Sprinkler Systems."

1.7.2. National Fire Protection Association No. 25, "Standard for the Inspection, Testing, and Maintenance of Water-Based Fire Protection Systems."

1.7.3. National Fire Protection Association No. 70, "National Electrical Code®".


1.7.4. National Fire Protection Association No. 72, "National Fire Alarm Code®".

1.8. Applicable Manuals. Manuals supplied by the manufacturers of components used in **UNITED Fire Systems PREACTION-PAC™** assemblies are included with this manual. In some cases, these manuals contain references that are **NOT APPLICABLE** to **PREACTION-PAC™** assemblies. The following tables detail these NOT APPLICABLE items. Care should be taken to be clear on what is applicable and what is not when referring to these manuals for installation, operation, inspection, and maintenance instructions.

PREACTION-PAC™
with NO BUILT-IN RELEASING CONTROL PANEL
INSTALLATION, OPERATION, AND MAINTENANCE MANUAL
P/N 10-500003-00N
VERSION 1.00 – NOVEMBER 2020

1.9 FM Approved Assemblies

Part Number Coding:



PREACTION-PAC™ assemblies with indicated part numbers are FM Approved. From time to time, custom-built units are supplied upon request. The components in these custom-built units retain their individual approvals, but these custom-built units are not FM Approved.

All FM Approved systems require the installation of an FM Approved preaction control panel.

When the **PREACTION-PAC™** is installed where FM Global is an AHJ, follow the requirements of FM Approvals Class Numbers 1011, 1012, 1013 and FM Global Property Loss Prevention Data Sheet 5-40 dated 2007, especially:

- Alarm control panels for automatic release of preaction sprinkler systems are required to have 90 hours of secondary power followed by 10 minutes of release power and alarm operation.
- Include the installation of Class A (Style D or E) initiating device circuits. All FM Approved systems / installations must be configured as Class A for Deluge and Preaction Releasing Service.
- Do not include abort switches to abort the preaction sprinkler actuation function.

PREACTION-PAC™
with NO BUILT-IN RELEASING CONTROL PANEL
INSTALLATION, OPERATION, AND MAINTENANCE MANUAL
P/N 10-500003-00N
VERSION 1.00 – NOVEMBER 2020

Table 1.9 – Approved PREACTION-PAC™ Assemblies with No Built-In Releasing Control Panel

| Part Number | Valve Size, in. | Valve Type | Supervisory Gas Source | Control Panel |
|-------------|-----------------|------------------|-----------------------------|---------------|
| | | | | |
| G320P21N | 2" | Double Interlock | 1/6 HP Compressor | No Panel |
| G320P2NN | 2" | Double Interlock | Pressure Maintenance Device | No Panel |
| | | | | |
| G330P21N | 3" | Double Interlock | 1/6 HP Compressor | No Panel |
| G330P22N | 3" | Double Interlock | 1/3 HP Compressor | No Panel |
| G330P23N | 3" | Double Interlock | 1/2 HP Compressor | No Panel |
| G330P2NN | 3" | Double Interlock | Pressure Maintenance Device | No Panel |
| | | | | |
| G340P21N | 4" | Double Interlock | 1/6 HP Compressor | No Panel |
| G340P22N | 4" | Double Interlock | 1/3 HP Compressor | No Panel |
| G340P23N | 4" | Double Interlock | 1/2 HP Compressor | No Panel |
| G340P2NN | 4" | Double Interlock | Pressure Maintenance Device | No Panel |
| | | | | |

PREACTION-PAC™
with NO BUILT-IN RELEASING CONTROL PANEL
INSTALLATION, OPERATION, AND MAINTENANCE MANUAL
P/N 10-500003-00N
VERSION 1.00 – NOVEMBER 2020

1.10. Installation.

1.10.1. Location. Locate the **PREACTION-PAC™** assembly as shown on the system shop drawings or design plans. The location should be dry, clean, and within the Approved temperature range of the assembly (+40 deg F to +110 deg F). Refer to Figure 4 for overall dimensions.

1.10.2. Unpacking, Placement & Leveling. Unpack the **PREACTION-PAC™** as follows:

1.10.2.1. Remove the outer carton and any other packing material surrounding the assembly.

1.10.2.2. Open the lower enclosure door.

1.10.2.3. Use a flat-bladed or Phillips screwdriver to remove the (4) bolts holding the assembly to the pallet. See Figure 5.


1.10.2.4. Close the lower enclosure door. Remove the unit from the pallet, and place in the intended installation location.

1.10.2.5. Level the unit:

1.10.2.5.1. Open the lower enclosure door.

1.10.2.5.2. Using a flat-bladed screwdriver, adjust the (4) leveling feet from inside the enclosure until all feet are firmly in contact with the floor. See Figure 5.

1.10.2.5.3. Using a spirit level, adjust the leveling feet until the assembly is level both front-to-back and side-to-side.



| Dimension | Inches |
|-----------|--------|
| A | 24.00 |
| B | 52.00 |
| C | 10.00 |
| D | 30.00 |
| E | 62.00 |

Figure 4 – Diagram - Overall Dimensions

PREACTION-PAC™
with NO BUILT-IN RELEASING CONTROL PANEL
INSTALLATION, OPERATION, AND MAINTENANCE MANUAL
P/N 10-500003-00N
VERSION 1.00 – NOVEMBER 2020





Figure 5 – Diagram - Location of Pallet Bolts and Leveling Feet

1.10.3. Serial Number. The serial number of each assembly is located on a permanent metal nameplate, located behind the upper enclosure door above the compressor disconnect switch. The serial number is coded as follows:



Note the serial number, date of installation, and date of commissioning on the front of this manual where indicated.

1.10.4. External Attachments.

1.10.4.1. Preaction Valve. Use Section 2 - Tyco Manual TFP1461 to guide the installation of inlet, outlet, and drain piping. See Figure 6 for details.

1.10.4.1.1. Inlet Piping. Inlet piping may be attached to the **PREACTION-PAC™** in one of two locations:

- The standard connection is at the lower right center of the lower enclosure. The assembly is pre-piped to accept inlet piping at this location. This location is labeled INLET. Remove the plastic protection cap from the inlet pipe, and use a field-supplied grooved coupling to make this connection.
- An optional connection at the lower left center of the lower enclosure. Remove the precut knockout from the lower left center of the lower enclosure. Remove the steel cap from the grooved coupling on the left side of the tee at the bottom of the enclosure. Attach the inlet piping to the left side of the tee using the grooved coupling. Remove the plastic protection cap from the lower right center inlet connection, and assemble the steel cap removed from the tee to the lower right connection using a field-supplied grooved coupling.




Failure to assemble the steel cap to the top inlet will result in property damage due to water escaping from the top inlet.

1.10.4.1.2. Outlet Piping. Outlet piping is attached to the **PREACTION-PAC™** in one location; at the top center of the lower enclosure. This location is labeled OUTLET. Remove the plastic protection cap from the outlet pipe, and used a field-supplied grooved coupling to make this connection.

1.10.4.1.3. Drain Piping. Drain piping is attached to the **PREACTION-PAC™** at a nipple located in the lower enclosure. The drain pipe may exit the enclosure on either the left or right side. Remove the precut knockout from the chosen side. Attach the drain pipe to the nipple with two field-supplied grooved couplings and a field-supplied grooved elbow.

PREACTION-PAC™
 with NO BUILT-IN RELEASING CONTROL PANEL
 INSTALLATION, OPERATION, AND MAINTENANCE MANUAL
 P/N 10-500003-00N
 VERSION 1.00 – NOVEMBER 2020

1.10.4.1.4. External Supervisory Gas Inlet. External supervisory gas inlet piping is attached to the **PREACTION-PAC™** in one location: the back center of the top surface of the lower enclosure. The connection point is a ½ NPT female bulkhead (through-wall) fitting. Make the field connection by removing the red plastic plug and plumbing to the location with ½ inch pipe, typically either steel or copper. PLEASE NOTE: This inlet option is only present on configurations with a pressure maintenance device.



NOTES:
 1. TRIM ELEMENTS AND UPPER ENCLOSURE REMOVED FOR CLARITY

| Dimension | Inches |
|-----------|--------|
| A | 15.00 |
| B | 12.50 |
| C | 9.86 |
| D | 8.86 |
| E | 5.75 |
| F | 12.50 |

Figure 6 – Diagram - Piping Attachment Details

PREACTION-PAC™
with NO BUILT-IN RELEASING CONTROL PANEL
INSTALLATION, OPERATION, AND MAINTENANCE MANUAL
P/N 10-500003-00N
VERSION 1.00 – NOVEMBER 2020

1.10.4.2. Terminal Strip. Use Figure 6 to guide the installation of connections to the terminal strip in the upper enclosure. Terminals for 110VAC power accept qty. (1) 10 ga. max. conductor. Terminals for signal switch and solenoid connection accept qty. (1) 12 ga. max or qty. (2) 16 ga. max conductors. NOTE: All conductors used for field wiring must comply with NFPA 70 – National Electrical Code. Power-limited and non-power limited conductors should be run with minimum 1/4" spacing within the upper enclosure. 110VAC power conductors are non-power-limited. Refer to the field-installed control panel instruction manual for information on the power- or non-power-limited status of the solenoid and signal conductors.




CAUTION



DO NOT drill or punch the upper enclosure to attach conduit. Use the knockouts supplied at the lower back of the upper enclosure. Failure to follow these instructions can result in damage to the assembly.

PREACTION-PAC™
with NO BUILT-IN RELEASING CONTROL PANEL
INSTALLATION, OPERATION, AND MAINTENANCE MANUAL
P/N 10-500003-00N
VERSION 1.00 – NOVEMBER 2020



**Figure 7a – Diagram –
Terminal Strip with Compressor Wiring Detail**

PREACTION-PAC™
with NO BUILT-IN RELEASING CONTROL PANEL
INSTALLATION, OPERATION, AND MAINTENANCE MANUAL
P/N 10-500003-00N
VERSION 1.00 – NOVEMBER 2020

| LEGEND | | |
|----------------|---|-------------------------|
| FIELD WIRING | | |
| | | COLOR OF TERMINAL BLOCK |
| 1 | 110 VAC GROUND FOR COMPRESSOR | GREEN/YELLOW |
| 2 | 110 VAC NEUTRAL FOR COMPRESSOR | WHITE |
| 3 | 110 VAC HOT FOR COMPRESSOR | BLACK |
| 4 | PREACTION SOLENOID WIRING (-) TO FIELD-INSTALLED CONTROL PANEL OR MODULE | GRAY |
| 5 | PREACTION SOLENOID WIRING (+) TO FIELD-INSTALLED CONTROL PANEL OR MODULE | RED |
| 6 | LOW AIR SIGNAL SWITCH WIRING (NO) TO FIELD-INSTALLED CONTROL PANEL OR MODULE | GRAY |
| 7 | LOW AIR SIGNAL SWITCH WIRING (COM) TO FIELD-INSTALLED CONTROL PANEL OR MODULE | GRAY |
| 8 | WATERFLOW SIGNAL SWITCH WIRING (NO) TO FIELD-INSTALLED CONTROL PANEL OR MODULE | BLUE |
| 9 | WATERFLOW SIGNAL SWITCH WIRING (COM) TO FIELD-INSTALLED CONTROL PANEL OR MODULE | BLUE |
| 10 | TAMPER SIGNAL SWITCH WIRING (NO) TO FIELD-INSTALLED CONTROL PANEL OR MODULE | YELLOW |
| 11 | TAMPER SIGNAL SWITCH WIRING (COM) TO FIELD-INSTALLED CONTROL PANEL OR MODULE | YELLOW |
| FACTORY WIRING | | |
| 12 | 110 VAC GROUND TO COMPRESSOR | GREEN/YELLOW |
| 13 | 110 VAC NEUTRAL TO COMPRESSOR | WHITE |
| 14 | 110 VAC HOT TO COMPRESSOR | BLACK |
| 15 | PREACTION SOLENOID WIRING (-) FROM LOWER ENCLOSURE | GRAY |
| 16 | PREACTION SOLENOID WIRING (+) FROM LOWER ENCLOSURE | RED |
| 17 | LOW AIR SIGNAL SWITCH WIRING (NO) FROM LOWER ENCLOSURE | GRAY |
| 18 | LOW AIR SIGNAL SWITCH WIRING (COM) FROM LOWER ENCLOSURE | GRAY |
| 19 | WATERFLOW SIGNAL SWITCH WIRING (NO) FROM LOWER ENCLOSURE | BLUE |
| 20 | WATERFLOW SIGNAL SWITCH WIRING (COM) FROM LOWER ENCLOSURE | BLUE |
| 21 | TAMPER SIGNAL SWITCH WIRING (NO) FROM LOWER ENCLOSURE | YELLOW |
| 22 | TAMPER SIGNAL SWITCH WIRING (COM) FROM LOWER ENCLOSURE | YELLOW |

Legend for Figure 7a

PREACTION-PAC™
with NO BUILT-IN RELEASING CONTROL PANEL
INSTALLATION, OPERATION, AND MAINTENANCE MANUAL
P/N 10-500003-00N
VERSION 1.00 – NOVEMBER 2020




Figure 7b – Diagram –
Terminal Strip with Pressure Maintenance Device Wiring Detail

PREACTION-PAC™
with NO BUILT-IN RELEASING CONTROL PANEL
INSTALLATION, OPERATION, AND MAINTENANCE MANUAL
P/N 10-500003-00N
VERSION 1.00 – NOVEMBER 2020

| LEGEND | | |
|----------------|---|-------------------------|
| FIELD WIRING | | |
| | | COLOR OF TERMINAL BLOCK |
| 4 | PREACTION SOLENOID WIRING (-) TO FIELD-INSTALLED CONTROL PANEL OR MODULE | GRAY |
| 5 | PREACTION SOLENOID WIRING (+) TO FIELD-INSTALLED CONTROL PANEL OR MODULE | RED |
| 6 | LOW AIR SIGNAL SWITCH WIRING (NO) TO FIELD-INSTALLED CONTROL PANEL OR MODULE | GRAY |
| 7 | LOW AIR SIGNAL SWITCH WIRING (COM) TO FIELD-INSTALLED CONTROL PANEL OR MODULE | GRAY |
| 8 | WATERFLOW SIGNAL SWITCH WIRING (NO) TO FIELD-INSTALLED CONTROL PANEL OR MODULE | BLUE |
| 9 | WATERFLOW SIGNAL SWITCH WIRING (COM) TO FIELD-INSTALLED CONTROL PANEL OR MODULE | BLUE |
| 10 | TAMPER SIGNAL SWITCH WIRING (NO) TO FIELD-INSTALLED CONTROL PANEL OR MODULE | YELLOW |
| 11 | TAMPER SIGNAL SWITCH WIRING (COM) TO FIELD-INSTALLED CONTROL PANEL OR MODULE | YELLOW |
| FACTORY WIRING | | |
| 15 | PREACTION SOLENOID WIRING (-) FROM LOWER ENCLOSURE | GRAY |
| 16 | PREACTION SOLENOID WIRING (+) FROM LOWER ENCLOSURE | RED |
| 17 | LOW AIR SIGNAL SWITCH WIRING (NO) FROM LOWER ENCLOSURE | GRAY |
| 18 | LOW AIR SIGNAL SWITCH WIRING (COM) FROM LOWER ENCLOSURE | GRAY |
| 19 | WATERFLOW SIGNAL SWITCH WIRING (NO) FROM LOWER ENCLOSURE | BLUE |
| 20 | WATERFLOW SIGNAL SWITCH WIRING (COM) FROM LOWER ENCLOSURE | BLUE |
| 21 | TAMPER SIGNAL SWITCH WIRING (NO) FROM LOWER ENCLOSURE | YELLOW |
| 22 | TAMPER SIGNAL SWITCH WIRING (COM) FROM LOWER ENCLOSURE | YELLOW |

Legend for Figure 7b

PREACTION-PAC™
with NO BUILT-IN RELEASING CONTROL PANEL
INSTALLATION, OPERATION, AND MAINTENANCE MANUAL
P/N 10-500003-00N
VERSION 1.00 – NOVEMBER 2020

1.10.4.2.1. Power. 110VAC, 3-wire, single-phase power is attached to the terminal strip in the upper enclosure. See Figure 7. Terminals for 110VAC power accept qty. (1) 10 ga. max. conductor. Current draw: With 1/6HP compressor = 6.6 amps; with 1/3HP compressor = 6.6 amps; with 1/2HP compressor = 8.0 amps; with pressure maintenance device = 0 amps.



DANGER



Only qualified electricians should connect incoming power to the assembly. Failure to follow this instruction could result in death or serious personal injury.

- A. Turn off circuit breaker at the main power distribution panel.
- B. Connect service ground conductor to terminal marked GROUND.
- C. Connect primary neutral conductor to terminal marked NEUTRAL.
- D. Connect primary hot conductor to terminal marked HOT.

1.10.4.3. Compressor. Where applicable. See Figure 7a. 110VAC, 3-wire, single-phase power is attached to the terminal strip in the upper enclosure. The compressor power is factory-wired to the terminal strip in the upper enclosure. The compressor pressure outlet is factory-attached to the system piping within the lower enclosure.

1.10.5. Prior To Placing In Service. Before placing the **PREACTION-PAC™** in service, perform the following steps. Ensure that all discrepancies are corrected before proceeding to the next step.

- 1.10.5.1.** Ensure the entire system is installed per the latest revision of all applicable shop drawings.
- 1.10.5.2.** Ensure all testing has been performed on the sprinkler piping per the requirements of the authority having jurisdiction and NFPA 13.
- 1.10.5.3.** Perform all preliminary tests on the field-installed control panel, field wiring, and field devices.
- 1.10.5.4.** Use Section 2 – Tyco Manual TFP1461 to perform all preliminary tests on the preaction valve, trim, and sprinkler piping.
- 1.10.5.5.** Perform all tests required to be witnessed by the authority having jurisdiction. Obtain AHJ approval of the installation.

1.10.6. Placing In Service.

- 1.10.6.1.** Verify that the water supply is on.
- 1.10.6.2.** Using Section 2 – Tyco Manual TFP1461, verify that all valves are in the proper position for in-service status. Verify that the three pressure gauges on the front of the lower enclosure are indicating expected values within expected limits.
- 1.10.6.3.** Ensure that the owner of the system has received adequate introductory training.
- 1.10.6.4.** Turn over this manual and the enclosure door keys to the owner. The manual may be stored in the pocket on the inside of the lower enclosure door.

PREACTION-PAC™
with NO BUILT-IN RELEASING CONTROL PANEL
INSTALLATION, OPERATION, AND MAINTENANCE MANUAL
P/N 10-500003-00N
VERSION 1.00 – NOVEMBER 2020

1.11. Operation.

- 1.11.1. Automatic.** Fully automatic operation of the system will be conducted by the field-installed control panel. Power from 110VAC and / or batteries is required for the control panel to function in this way. No manual intervention is required for the control panel to perform its functions. Manual intervention to acknowledge and silence signals may be performed.



IMPORTANT

Fusing of a sprinkler head by heat is necessary for water to be discharged onto a fire, even after operation of automatic fire detectors.

- 1.11.2. Manual.** Manual operation of the preaction valve is accomplished with the manual release valve. Open the door marked IN CASE OF FIRE OPEN DOOR AND PULL LEVER. No key is needed to open this door. Pull the lever. No power is needed to open the preaction valve in this manner. The door may not be closed until the lever is restored to its normal position.



IMPORTANT

Fusing of a sprinkler head by heat is necessary for water to be discharged onto a fire, even after operation of the manual station valve.

- 1.11.3. Restoring To Service.** After automatic or manual system operation, follow instructions in Section 2 – Tyco Manual TFP1461 to restore the **PREACTION-PAC™** to service.

- 1.12. Inspection, Testing, and Maintenance.** Regular inspection, testing and maintenance of the **PREACTION-PAC™** assembly is essential to the assembly's continued proper operation. Follow all instructions in the documents described in this section. Pay particular attention to the required minimum interval for each item of inspection, testing, and maintenance. The owner of the system (or their designated representative) is responsible for the overall condition of the system, and ensuring that all inspection, testing, and maintenance items are conducted as recommended.



IMPORTANT

The **UNITED Fire Systems PREACTION-PAC™** sprinkler valve assembly is a vital part of the fire protection of any facility where these units are installed. Life safety and property protection depends on continuing proper operation of the assembly. The owner of the **PREACTION-PAC™** is responsible for the condition of the assembly and its continued proper operation. **UNITED Fire Systems** strongly recommends that all owners of **PREACTION-PAC™** engage the services of qualified, trained fire protection professionals to inspect, test, maintain, and repair the assembly.

- 1.12.1. Inspection.** Inspection involves carrying out a set of procedures to discover and note any and all discrepancies that could render the system impaired, inoperative, or ineffective. The result of an inspection is a comprehensive list of these discrepancies. Inspection does not specifically include maintenance or repair; however, maintenance and repair can be and usually is conducted at the time of inspection.
- 1.12.2. Testing.** Testing involves carrying out procedures to discover if tested components function as intended. Testing is an integral part of performing inspection. Testing is also done after the performance of some maintenance procedures.
- 1.12.3. Maintenance.** Maintenance involves carrying out procedures to ensure that maintained components continue to function as intended. Maintenance is usually preventive in nature. Maintenance can be conducted during inspection.
- 1.12.4. Repair.** Repair involves carrying out procedures to correct the deficiencies found during inspection, or as a result of other events such as system actuation or control panel trouble / alarm signals.
- 1.12.5. Documents Relevant To Inspection, Testing, Maintenance, and Repair.**
- 1.12.5.1.** Tyco Manual TFP1461.
 - 1.12.5.2.** General Air Products Manual OILLESSINST.
 - 1.12.5.3.** United Fire Systems Instruction Sheet UFS-710.
 - 1.12.5.4.** National Fire Protection Association No. 25, "Standard for the Inspection, Testing, and Maintenance of Water-Based Fire Protection Systems."
 - 1.12.5.5.** National Fire Protection Association No. 72, "National Fire Alarm Code®"

SECTION

2

Tyco Manual TFP1461

DV-5A Automatic Water
Control Valve, Double
Interlock Preaction,
Electric/Pneumatic Actuation

DV-5A Automatic Water Control Valve Double Interlock Preaction Electric/Pneumatic Actuation Fire Protection Systems 1-1/2 Inch to 8 Inch (DN40 to DN200)

General Description

The TYCO DV-5A Automatic Water Control Valves are diaphragm type valves that can be used in double interlock preaction fire protection systems. When properly trimmed, the double seat design of the DV-5A Valve also provides actuation of fire alarms upon system operation.

The diaphragm style design of the DV-5A Valve allows external resetting, providing for easy resetting of a deluge system without having to open a valve handhole cover to manually reposition a clapper and/or latch mechanism. Simply re-pressurizing the diaphragm chamber resets the valve.

The DV-5A features internal and external coating of the valve to provide corrosion resistance. The external corrosion resistance of the epoxy coating permits the use of the DV-5A in corrosive atmospheres associated with many types of industrial processing plants and outdoor installations.

The DV-5A Valves are offered with the DV-5A Valve and separately ordered semi-assembled trim shown in Figures 6 and 7, or, for ease of installation, with DV-5A Valve completely trimmed with or without a System Main Control Valve.

Double interlock preaction systems are designed for use in applications, such as refrigerated areas, requiring the maximum degree of protection against inadvertent flooding of the sprinkler system piping. In order for a double interlock preaction system to automatically activate, two independent events must occur. First, the electric detection system must operate, and secondly, an automatic sprinkler on the system piping must operate. Typically, the electric detection system is designed to operate before any automatic sprinkler. Operation of just the electric detection,



Available End Connections and Weights — lb/(kg)

| End Connection | | Nominal Valve Size ANSI Inches (DN) | | | | | |
|----------------|--------|---|--------------|--------------|---------------|---------------|----------------|
| Inlet | Outlet | 1-1/2 (40) | 2 (50) | 3 (80) | 4 (100) | 6 (150) | 8 (200) |
| Thread | Thread | 26 (11,8) | 25 (11,3) | N/A | N/A | N/A | N/A |
| Groove | Groove | 25 (11,3) | 25 (11,3) | 60 (27,2) | 95 (43,1) | 177 (80,3) | 327 (148,3) |
| Flange | Groove | N/A | N/A | 66 (30,0) | 106 (48,1) | 190 (86,2) | 346 (157,0) |
| Flange | Flange | N/A | N/A | 72 (32,7) | 116 (52,6) | 204 (92,5) | 365 (165,6) |

or just the opening of a sprinkler will not allow the DV-5A Valve to open and permit water to flow into the normally dry sprinkler system piping. However, operation of just the electric detection system or the opening of a sprinkler (loss of system air pressure) will result in a supervisory alarm to notify the building occupants of a condition needing attention so as to avoid inadvertent flooding of the system piping.

In the case of Electric/Pneumatic Actuation, a solenoid valve and a dry pilot actuator connected in series is used to

hold the DV-5A Valve closed by locking pressure in the diaphragm chamber of the DV-5A Valve. In the event of a fire, a releasing panel is initiated by a fire detection or electric manual pull station, to allow the solenoid valve to open, and subsequently loss of system air pressure due to opening of an automatic sprinkler will result in opening of the dry pilot actuator. Opening of both the solenoid valve and dry pilot actuator results in operation of the DV-5A Valve.

IMPORTANT

Refer to Technical Data Sheet TFP2300 for warnings pertaining to regulatory and health information.

| Item | Description | Qty. | Nominal Valve Size ANSI Inch (DN) | | | | | |
|------|-----------------|----------------|-----------------------------------|-----------|-----------|-----------|-----------|-----------|
| | | | 1 1/2 (DN40) | 2 (DN50) | 3 (DN80) | 4 (DN100) | 6 (DN150) | 8 (DN200) |
| | | | P/N | P/N | P/N | P/N | P/N | P/N |
| 1 | Valve Body | 1 | N/R | N/R | N/R | N/R | N/R | N/R |
| 2 | Diaphragm | 1 | 545000020 | 545000020 | 545000030 | 545000040 | 545000060 | 545000080 |
| 3 | Diaphragm Cover | 1 | N/R | N/R | N/R | N/R | N/R | N/R |
| 4 | Hex Bolt, Short | 2 ^a | 545100001 | 545100001 | 545100002 | 545100003 | 545100004 | 545100003 |
| 5 | Hex Bolt, Long | 2 | 545100011 | 545100011 | 545100012 | 545100013 | 545100014 | 545100015 |
| 6 | Lift Washer | 2 ^b | N/A | N/A | 545100021 | 545100022 | 545100023 | 545100022 |
| 7 | Hex Nut | 2 | 545100031 | 545100031 | 545100032 | 545100033 | 545100034 | 545100033 |
| 8 | Hoist Ring | 2 | 545100041 | 545100041 | 545100041 | 545100041 | 545100041 | 545100041 |
| 9 | Flat Washer | 2 | N/A | N/A | 545100024 | 545100025 | 545100026 | 545100025 |

NOTES

a. Hex Bolt, Short, Qty. 6 in 6 and 8 inch (DN150 and DN200) assemblies
b. Lift Washer not used in 1 1/2 and 2 inch (DN40 and DN50) assemblies
c. N/R = Not Replaceable
d. Order replacements parts only via Part Numbers given, do not replace Hex Bolt, Hex Nut, Lift Washer or Hoist Ring with common hardware parts

FIGURE 1
DV-5a VALVE ASSEMBLY AND REPLACEMENT PARTS

| Nominal Valve Size ANSI Inches (DN) | Flange Drilling Specification | | | | | | | | | | | |
|-------------------------------------|---------------------------------------|-------------|---|--------------------------------|-------------|----|------------------|-------------|----|-------------------|-------------|---|
| | Nominal Dimensions in Inches and (mm) | | | | | | | | | | | |
| | ANSI B16.1 ^a (Class 125) | | | ISO 7005-2 (PN16) ^b | | | JIS B 2210 (10K) | | | AS 2129 (Table E) | | |
| | A | B | N | A | B | N | A | B | N | A | B | N |
| 3 (80) | 6.00 (152,4) | 0.75 (19,0) | 4 | 6.30 (160,0) | 0.75 (19,0) | 8 | 5.90 (150,0) | 0.59 (15,0) | 8 | 5.75 (146,0) | 0.71 (18,0) | 4 |
| 4 (100) | 7.50 (190,5) | 0.75 (19,0) | 8 | 7.09 (180,0) | 0.75 (19,0) | 8 | 6.89 (175,0) | 0.60 (15,0) | 8 | 7.00 (178,0) | 0.71 (18,0) | 8 |
| 6 (150) | 9.50 (241,3) | 0.88 (22,2) | 8 | 9.45 (240,0) | 0.91 (23,0) | 8 | 9.45 (240,0) | 0.75 (19,0) | 8 | 9.25 (235) | 0.87 (22,0) | 8 |
| 8 (200) | 11.75 (298,5) | 0.88 (22,2) | 8 | 11.61 (295,0) | 0.91 (23,0) | 12 | 11.42 (290,0) | 0.75 (19,0) | 12 | 11.50 (292,0) | 0.87 (22,0) | 8 |

NOTES:

a. Same drilling as for ANSI B16.5 (Class 150) and ANSI B16.42 (Class 150)
b. Same drilling as for BS 4504 Section 3.2 (PN16) and DIN 2532 (PN16)

TABLE A
FLANGE DRILLING SPECIFICATIONS

| Port | Port Description | Port Sizes, NPT Inch per ANSI B1.20.1 | | | | | |
|------|------------------------------------|---------------------------------------|-------------|-------------|--------------|--------------|--------------|
| | | 1 1/2 (DN40) | 2 (DN50) | 3 (DN80) | 4 (DN100) | 6 (DN150) | 8 (DN200) |
| P1 | Diaphragm Chamber Supply | 1/2 | 1/2 | 1/2 | 1/2 | 1/2 | 1/2 |
| P2 | Water Supply Pressure & Alarm Test | 1/2 | 1/2 | 1/2 | 1/2 | 1/2 | 1/2 |
| P3 | Alarm Actuation | 3/4 | 3/4 | 3/4 | 3/4 | 3/4 | 3/4 |
| P4 | Automatic Drain Valve | 1/2 | 1/2 | 1/2 | 1/2 | 1/2 | 1/2 |
| P5 | System Drain | 3/4 | 3/4 | 3/4 | 3/4 | 3/4 | 3/4 |
| P6 | Main Drain | 3/4 | 3/4 | 1-1/4 | 2 | 2 | 2 |
| P7 | System Air Supply | 1/2 | 1/2 | 1/2 | 1/2 | 1/2 | 1/2 |




FIGURE 2A
SET CONDITION




FIGURE 2B
OPERATED CONDITION




FIGURE 2C
SYSTEM DRAIN CONDITION





FIGURE 2D
RESIDUAL DRAIN CONDITION

FIGURE 2
DV-5A VALVE OPERATION, PREACTION SYSTEMS



NOTICE

The DV-5A Valves described herein must be installed and maintained in compliance with this document, as well as with the applicable standards of the NATIONAL FIRE PROTECTION ASSOCIATION (NFPA), in addition to the standards of any other authorities having jurisdiction. Failure to do so may impair the performance of these devices.

The owner is responsible for maintaining their fire protection system and devices in proper operating condition. Contact the installing contractor or product manufacturer with any questions.

Technical Data

Approvals

UL/C-UL Listed
 FM Approved

Listings and Approvals are based on DV-5A being trimmed as described in this technical data sheet.

DV-5A Valve

Components for the 1 1/2 thru 8 Inch (DN40 thru DN200) DV-5A Valves are shown in Figure 1. The DV-5A Valves are for vertical installations. They are rated for use at a service pressures of 20 to 300 psi (1,4 to 20,7 bar).

The take-out dimensions are shown in Figure 3, and flanged connections are available drilled per ANSI, ISO, AS, and JIS specifications (See Table A). Threaded inlet and outlet connections are available in NPT or ISO 7-1. Threaded port connections are NPT threaded.

NOTE: PN16 flanges are pressure rated to 16 bar.

Valve Trim

The maximum pressure rating for the Electric Pneumatic Double Interlock Preaction Trim is the lesser of 250 psi (17,2 bar) or the separately ordered solenoid valve per Technical Data Sheet TFP2180

When the system pressure is greater than 175 psi (12,1 bar), provision is to be made to replace the standard order 300 psi (20,7 bar) Water Pressure Gauges with separately ordered 600 psi (41,4 bar) Water Pressure Gauges.

If the addition of an Alarm Control Valve is desired or required by the local AHJ, the Alarm Control Valve noted as Item H in Figure 8 is to be a separately ordered electronically supervised normally open valve.

External trim connections are NPT threaded. EMEA trim is provided with NPT x ISO 7-1 thread adapters.

Pressure Loss

Refer to Graph A

Actuation Options

Refer to subsections for Electric/Electric Actuation or Electric/Pneumatic Actuation.

Materials of Construction

Valve Body

Epoxy coated ductile iron per ASTM A536-77, Grade 65-45-12

Diaphragm Cover

Epoxy coated ductile iron per ASTM A536-77, Grade 65-45-12

Diaphragm


Polyester fabric reinforced, TEFLON coated, EPDM rubber per ASTM D2000

Diaphragm Cover Fasteners

Aluminum zinc coated steel

Common Hardware Trim

- Common hardware pipe fittings are galvanized or black as required and are malleable per ASME B16.3.
- Common hardware pipe nipples are galvanized or black as required and are Schedule 40 per ASTM A53 or A135.
- Common hardware compression fitting are brass per ASTM B16
- Common hardware tubing is Type L per ASTM B88



Operation

The TYCO DV-5A Valve is a diaphragm style valve that depends upon water pressure in the Diaphragm Chamber (see Figure 2A) to hold the Diaphragm closed against the water supply pressure.


When the DV-5A Valve is set for service, the Diaphragm Chamber is pressurized through the trim connections from the inlet side of the system's main control valve.

Opening of a solenoid valve for Electric/Pneumatic Actuation (see Figure 4) trips the Model MRA-1 Manual Reset Actuator. Tripping the MRA-1 releases water from the DV-5A Diaphragm Chamber faster than it can be replenished through the 1/8 in. (3.2 mm) restriction located in the diaphragm chamber supply connection. Release of water through the

MRA-1 results in a rapid pressure drop in the DV-5A Diaphragm Chamber. The force differential applied through the Diaphragm to hold the Diaphragm in the set position is then reduced below the valve trip point. The water supply pressure then forces the Diaphragm open permitting water to flow into the system piping, as well as through the Alarm Port to actuate the system alarms (see Figure 2B).

Upon opening of the DV-5A Valve, the Model MRA-1 Manual Reset Actuator opens to constantly vent the DV-5A Diaphragm Chamber to "hydraulically latch" the DV-5A in the tripped position until manually reset.

See the Electric/Pneumatic section for additional information.



Electric/ Pneumatic Actuation

System Design Considerations

Because a double interlock preaction system requires time for a drop in system air pressure to occur (concurrently with the response time for the separate fire detection system) before it will allow water to enter the system piping, this system has characteristics similar to a dry pipe sprinkler system. Therefore, the system design considerations for a dry pipe system are normally applied to a double interlock preaction system — including a 30% increase in design area; a maximum 1 minute water delivery time for system capacities of 500 gallons (1890 liters) or more; and, prohibition of gridded system piping.

In order to readily perform the System Inspection Procedure described in the Care and Maintenance section, it is recommended that a System Shut-Off Valve be installed above the DV-5A Valve, as shown in Figure 4. The

System Shut-Off Valve should be a listed or approved (as appropriate) indicating valve with a supervisory switch to monitor the normally open position.

Detection System

The Double Interlock Preaction System With Electric/Pneumatic Actuation Trim provides for electric operation of the DV-5A Valve by a detection system consisting of electrical devices such as heat sensitive thermostats, smoke detectors, and/or electric manual pull stations. Information on the various types of separately ordered Solenoid Valves that may be used with this trim package is given in Technical Data Sheet TFP2180. Nominal installation dimensions for the Double Interlock Preaction System With Electric/Pneumatic Actuation Trim are shown in Figure 5.


The Deluge Valve Releasing Panel (automatic control unit) with battery back-up, fire detection devices, manual pull stations, and signaling devices that are utilized with the Double Interlock Preaction System With Electric/Pneumatic Actuation must be UL Listed, ULC Listed, C-UL Listed, or FM Approved, as applicable.

NOTICE

The normally closed, de-energized solenoid Valve is separately ordered and selected based on the required laboratory approval acceptable to the authority having jurisdiction. Refer to technical data Sheet TFP2180 for specific laboratory approvals.

Consult with the authority having jurisdiction regarding installation criteria pertaining to electric actuation circuitry.

Due to the functionality of the Model MRA-1 Manual Reset Actuator, the release circuit of the releasing panel need only provide the minimum typical ten minutes of alarm condition intended to energize the Solenoid Valve to open. After the ten minute duration, at which point should the Solenoid Valve become de-energized and close (especially while operating under battery back-up), the MRA-1 will have already automatically opened, thereby preventing the DV-5A Diaphragm Chamber from becoming re-pressurized, and preventing an inadvertent closing of the DV-5A during a fire event.



Notes:

The dew point of the pilot line air pressure must be maintained below the lowest ambient temperature to which the dry pilot actuation system will be exposed. Accumulation of water in the pilot line connection to the Actuator will lower the air pressure at which the actuator will open and possibly prevent proper operation. Also, introduction of moisture into the pilot lines exposed to freezing temperatures can create an ice buildup that could prevent proper operation of the Actuator.

An air dryer must be installed where the moisture content of the air supply is not properly controlled at less than the required value.

It is recommended that an AMD-3 Nitrogen Maintenance Device be utilized in dry pilot actuation system applications where the dew point must be maintained below -20°F (-29°C). Refer to Technical Data Sheet TFP1241.

GRAPH B
DV-5A VALVE DOUBLE INTERLOCK PREACTION SYSTEM
AIR PRESSURE REQUIREMENTS

WARNING

If the delay between electric actuation and subsequent sprinkler activation is anticipated to be greater than 10 minutes, adjust the battery back-up calculation accordingly. Inadequate battery back-up may result in failure of the system to operate in the event of a fire during a power failure.

System Air Pressure Requirements

The required system air pressure for the Double Interlock Preaction System with Electric/Pneumatic Actuation is shown in Graph B as a function of the anticipated water supply pressure. It is recommended that the system air pressure be maintained by one of the following methods:

- A maximum 200 psi (13,8 bar) plant air supply in combination with the Model AMD-1 Air Maintenance Device described in Technical Data Sheet TFP1221
- A dedicated air compressor in combination with the Model AMD-2 Air Maintenance Device described in Technical Data Sheet TFP1231

- A maximum 3000 psi (206,9 bar) nitrogen cylinder in combination with the Model AMD-3 Nitrogen Maintenance Device described in Technical Data Sheet TFP1241

NOTICE

The dew point of the air or nitrogen supply, for a system exposed to freezing conditions, must be maintained below the lowest ambient temperature to which the system piping will be exposed. Introduction of moisture into the system piping can create ice buildup which could prevent proper operation of the system.

The Air Pressure Relief Valve is typically set to crack open at 5 psi (0,34 bar) greater than the required system air pressure provided in Graph B.

Installation

The TYCO DV-5A Valve is to be installed in accordance with this section.

NOTICE

DV-5A Automatic Water Control Valves are designed to be used in freshwater systems. When the supply is from an alternative source such as brackish water, saltwater, or contains additives such as foam, the limited warranty is reduced to one year from the time of installation. An increase in frequency of inspections is required when the valve is exposed to such supplies and other corrosive conditions or chemicals that could impact valve materials or the operation of the assembly. The system and all components must be designed accordingly for the increased demand. It is required to thoroughly flush the valve and trim assembly with freshwater and reset to the set condition after each operation.

Proper operation of the DV-5A Valves depends upon their trim being installed in accordance with the instructions given in this technical data sheet. Failure to follow the appropriate trim diagram may prevent the DV-5A Valve from functioning properly, as well as void approvals and the manufacturer's warranties.

The DV-5A Valve must be installed in a readily visible and accessible location.

The DV-5A Valve and associated trim must be maintained at a minimum temperature of 40°F (4°C).

Heat tracing of the DV-5A Valve or its associated trim is not permitted. Heat tracing can result in the formation of hardened mineral deposits that are capable of preventing proper operation.

Always open the system control valves slowly to avoid a sudden rush of water entering the system.

The DV-5A Valve is to be installed in accordance with the following criteria:

Step 1. All nipples, fittings, and devices must be clean and free of scale and burrs before installation. Use pipe thread sealant sparingly on male pipe threads only.

Step 2. The DV-5A Valve must be trimmed in accordance with one of the trim illustrations shown in Figures 6 or 7, as applicable.

Note: *If the addition of an Alarm Control Valve is desired or required by the local AHJ, the Alarm Control Valve noted as Item H in Figure 8 is to be a separately ordered electronically supervised normally open valve.*

Step 3. Care must be taken to ensure that check valves, strainers, globe valves, etc., are installed with the flow arrows in the proper direction.

Step 4. Drain tubing to the Drip Funnel must be installed with smooth bends that will not restrict flow.

Step 5. The Main Drain and Drip Funnel Drain may be interconnected provided a check valve is located at least 12 in. (300 mm) below the Drip Funnel.

Step 6. Suitable provision must be made for disposal of drain water. Drainage water must be directed such that it will not cause accidental damage to property or danger to persons.

Step 7. Connect the Diaphragm Supply Valve to the inlet side of the System Main Control Valve in order to facilitate setting of the DV-5A Valve (see Figure 8).

Step 8. An Inspector's Test Connection is to be located on the sprinkler system at the most hydraulically demanding location.

Step 9. A suitable automatic air (nitrogen) supply, as described in the Electric/Pneumatic Actuation sub-section, is to be installed in accordance with the applicable technical data sheet. The minimum air pressure is to be in accordance with the referenced sub-sections.

Step 10. A desiccant dryer, when specified, is to be installed between a drip leg and the Air Maintenance Device.

Step 11. The Low Pressure Switch on falling pressure in the Electric/Pneumatic Actuation is to be adjusted so that the low pressure alarm setting is set at approximately 6 psi (0,4 bar) below the minimum system service pressure requirement shown in Graph B.


Step 12. Unused Pressure Alarm Switch connections must be plugged.

Step 13. The Pressure Relief Valve on rising pressure is to be at 5 psi (0,34 bar) higher than the required system air pressure, or be reset in accordance with the requirements of the authority having jurisdiction.

To reset the Pressure Relief Valve, first loosen the jam nut and then adjust the cap accordingly, clockwise for a higher pressure setting or counter clockwise for a lower pressure setting. After verifying the desired pressure setting, tighten the jam nut.

Step 14. Conduit and electrical connections are to be made in accordance with the applicable standards of the approval agency.


Step 15. Before a system hydrostatic test is performed, the DV-5A Diaphragm Chamber is to be depressurized, the Automatic Drain Valve is to be temporarily replaced with a plug, and the Diaphragm Cover Bolts must be uniformly and securely tightened using a cross-draw sequence. After tightening, double-check to make certain that all of the Diaphragm Cover Bolts are securely tightened. See Table B in the Care and Maintenance section for torque specifications.



Notes:

1. Port Connections P1 through P7 are described in Figure 2.
2. External Trim Connections C1 through C5 are described in Figure 8.
3. When ordering pre-assembled "DV-5A Valve with Galvanized Trim" or pre-assembled "DV-5A Valve with Galvanized Trim and Butterfly Valve", Items A1 through A10 are provided, as applicably related to valve size, and Item A7 is provided as P/N 52-287-1-124 described in Technical Data Sheet TFP2180.
4. When ordering DV-5A Trim separately from the DV-5A Valve, Items A1 through A10 are separately ordered, as applicably related to valve size. Water Pressure Gauges for EMEA valve trim are also separately ordered.

FIGURE 5
DV-5A VALVES
DOUBLE INTERLOCK PREACTION ELECTRIC/PNEUMATIC ACTUATION TRIM
SEMI-ASSEMBLED



| ITEM | QTY. | DESCRIPTION | CH | 1 1/2 IN. (DN40) | 2 IN. (DN50) | 3 IN. (DN80) | 4 IN. (DN100) | 6 IN. (DN150) | 8 IN. (DN200) |
|------|------|--|----|--|--------------------|------------------------|--------------------|--------------------|--------------------|
| 26 | 1 | ELBOW | ✓ | 1/2" x 45° | 1/2" x 45° | 1/2" x 45° | 1/2" x 45° | 1/2" x 45° | 1/2" x 45° |
| 27 | 4 | ELBOW | ✓ | 1/2" x 90° | 1/2" x 90° | 1/2" x 90° | 1/2" x 90° | 1/2" x 90° | 1/2" x 90° |
| 28 | 1 | CROSS | ✓ | 1/2" | 1/2" | 1/2" | 1/2" | 1/2" | 1/2" |
| 29 | 2 | TEE | ✓ | 1/2" | 1/2" | 1/2" | 1/2" | 1/2" | 1/2" |
| 30 | 1 | REDUCING TEE | ✓ | 1/2" x 1/4" x 1/2" | 1/2" x 1/4" x 1/2" | 1/2" x 1/4" x 1/2" | 1/2" x 1/4" x 1/2" | 1/2" x 1/4" x 1/2" | 1/2" x 1/4" x 1/2" |
| 31 | 2 | REDUCING TEE | ✓ | 1/2" x 1/2" x 1/4" | 1/2" x 1/2" x 1/4" | 1/2" x 1/2" x 1/4" | 1/2" x 1/2" x 1/4" | 1/2" x 1/2" x 1/4" | 1/2" x 1/2" x 1/4" |
| 32 | 2 | REDUCING TEE | ✓ | 3/4" x 1/2" x 3/4" | 3/4" x 1/2" x 3/4" | 3/4" x 1/2" x 3/4" | 3/4" x 1/2" x 3/4" | 3/4" x 1/2" x 3/4" | 3/4" x 1/2" x 3/4" |
| 33 | 1 | REDUCING TEE | ✓ | 3/4" x 3/4" x 3/4" | 3/4" x 3/4" x 3/4" | 1 1/4" x 1 1/4" x 3/4" | 2" x 2" x 3/4" | 2" x 2" x 3/4" | 2" x 2" x 3/4" |
| 34 | 1 | PIPE NIPPLE | ✓ | 1/4" x CLOSE | 1/4" x CLOSE | 1/4" x CLOSE | 1/4" x CLOSE | 1/4" x CLOSE | 1/4" x CLOSE |
| 35 | 1 | PIPE NIPPLE | ✓ | 1/4" x 1 1/2" | 1/4" x 1 1/2" | 1/4" x 1 1/2" | 1/4" x 1 1/2" | 1/4" x 1 1/2" | 1/4" x 1 1/2" |
| 36 | 6 | PIPE NIPPLE | ✓ | 1/2" x CLOSE | 1/2" x CLOSE | 1/2" x CLOSE | 1/2" x CLOSE | 1/2" x CLOSE | 1/2" x CLOSE |
| 37 | 4 | PIPE NIPPLE | ✓ | 1/2" x 1 1/2" | 1/2" x 1 1/2" | 1/2" x 1 1/2" | 1/2" x 1 1/2" | 1/2" x 1 1/2" | 1/2" x 1 1/2" |
| 38 | 1 | PIPE NIPPLE | ✓ | 1/2" x 2" | 1/2" x 2" | 1/2" x 2" | 1/2" x 2" | 1/2" x 2" | 1/2" x 2" |
| 39 | 2 | PIPE NIPPLE | ✓ | 1/2" x 2 1/2" | 1/2" x 2 1/2" | 1/2" x 2 1/2" | 1/2" x 2 1/2" | 1/2" x 2 1/2" | 1/2" x 2 1/2" |
| 40 | 1 | PIPE NIPPLE | ✓ | 1/2" x 3" | 1/2" x 3" | 1/2" x 3" | 1/2" x 3" | 1/2" x 3" | 1/2" x 3" |
| 41 | 1 | PIPE NIPPLE | ✓ | 1/2" x 5" | 1/2" x 5" | 1/2" x 5" | 1/2" x 5" | 1/2" x 5" | 1/2" x 5" |
| 42 | 1 | PIPE NIPPLE | ✓ | 3/4" x 1 1/2" | 3/4" x 1 1/2" | 3/4" x 1 1/2" | 3/4" x 1 1/2" | 3/4" x 1 1/2" | 3/4" x 1 1/2" |
| 43 | 1 | PIPE NIPPLE | ✓ | 3/4" x 4 1/2" | 3/4" x 4 1/2" | 3/4" x 4 1/2" | 3/4" x 4 1/2" | 3/4" x 4 1/2" | 3/4" x 4 1/2" |
| 44 | 1 | TUBING, MRA-1 DRAIN | | 545100065 | 545100065 | 545100066 | 535002140 | 535002160 | 535002180 |
| 45 | 1 | TUBING, MC-2 DRAIN | | 535000220 | 535000220 | 535000230 | 535000240 | 535000260 | 535000280 |
| 46 | 1 | TUBING, DP-1 DRAIN | | 535001220 | 535001220 | 535001230 | 535001240 | 535001260 | 535001280 |
| 47 | 1 | TUBING ASSY, ALARM TEST INTERCONNECT | | 535000320 | 535000320 | 535000330 | 535000340 | 535000360 | 535000380 |
| 48 | 1 | TUBING ASSY, ACTUATION INTERCONNECT | | 535001320 | 535001320 | 535001330 | 535001340 | 535001360 | 535001380 |
| 49 | 1 | TUBING ASSY, SYSTEM DRAIN | | 535000420 | 535000420 | 535000430 | 535000440 | 535000460 | 535000480 |
| 50 | 1 | PIPE NIPPLE | ✓ | 1/2" x 3 1/2" | 1/2" x 3 1/2" | 1/2" x 4 1/2" | 1/2" x 5 1/2" | 1/2" x 5 1/2" | 1/2" x 6 3/4" |
| 51 | 1 | PIPE NIPPLE | ✓ | 1/2" x 5" | 1/2" x 5" | 1/2" x 5 1/2" | 1/2" x 5 1/2" | 1/2" x 5 1/2" | 1/2" x 6 1/2" |
| 52 | 1 | PIPE NIPPLE | ✓ | 1/2" x 5" | 1/2" x 5" | 1/2" x 4 1/2" | 1/2" x 5" | 1/2" x 7 1/2" | 1/2" x 9 1/2" |
| 53 | 1 | PIPE NIPPLE | ✓ | 1/2" x 4 1/2" | 1/2" x 4 1/2" | 1/2" x 4 1/2" | 1/2" x 4 1/2" | 1/2" x 4 1/2" | 1/2" x 4 1/2" |
| 54 | 1 | PIPE NIPPLE | ✓ | 1/2" x 8 1/2" | 1/2" x 8 1/2" | 1/2" x 8 1/2" | 1/2" x 8 1/2" | 1/2" x 8 1/2" | 1/2" x 8 1/2" |
| 55 | 1 | PIPE NIPPLE | ✓ | 3/4" x 5" | 3/4" x 5" | 3/4" x 6" | 3/4" x 7" | 3/4" x 9" | 3/4" x 11 1/2" |
| 56 | 1 | PIPE NIPPLE | | 3/4" x 4 1/2" | 3/4" x 4 1/2" | 1 1/4" x 3 1/4" | 2" x 3" | 2" x 3" | 2" x 3" |
| 57 | 1 | PIPE NIPPLE | | 3/4" x 6 1/2" | 3/4" x 6 1/2" | 1 1/4" x 5 1/2" | 2" x 5" | 2" x 6" | 2" x 8" |
| 58 | 2 | WATER PRESSURE GAUGE, 300 PSI / 2000 kPa (AMER/APAC) | | 923431005 | 923431005 | 923431005 | 923431005 | 923431005 | 923431005 |
| 58 | 2 | WATER PRESSURE GAUGE, 20 bar / 2000 kPa (EMEA) | | 025500013 | 025500013 | 025500013 | 025500013 | 025500013 | 025500013 |
| 59 | 1 | AIR PRESSURE GAUGE, 80 PSI / 550 kPa RETARDED TO 250PSI / 1750 kPa | | 923431012 | 923431012 | 923431012 | 923431012 | 923431012 | 923431012 |
| 60 | 1 | LABEL | | 545003005 | 545003005 | 545003005 | 545003005 | 545003005 | 545003005 |
| 61 | 1 | LABEL WIRE | | — | — | — | — | — | — |
| A1 | 1 | DV-5A VALVE | | SEE ORDERING PROCEDURE, SEPARATE DV-5A VALVES WITHOUT TRIM, FOR PART NUMBERS | | | | | |
| A2 | 1 | WATERFLOW PRESSURE ALARM SWITCH, PS10-2 (AMER/APAC) | | 25710 | 25710 | 25710 | 25710 | 25710 | 25710 |
| A2 | 1 | WATERFLOW PRESSURE ALARM SWITCH, PS10-1 (EMEA) | | 0260 | 0260 | 0260 | 0260 | 0260 | 0260 |
| A3 | 1 | LOW AIR PRESSURE ALARM SWITCH, PS40-2 (AMER/APAC) | | 25730 | 25730 | 25730 | 25730 | 25730 | 25730 |
| A3 | 1 | LOW AIR PRESSURE ALARM SWITCH, PS40-1 (EMEA) | | 0262 | 0262 | 0262 | 0262 | 0262 | 0262 |
| A4 | 1 | BUTTERFLY VALVE, G x G | | 51024A | 51021A | — | — | — | — |
| A4 | 1 | BFV-300 BUTTERFLY VALVE, G x G | | — | — | 59300G030WS | 59300G040WS | 59300G060WS | 59300G080WS |
| A5 | 2 | FIGURE 577 RIGID GROOVED COUPLING | | 57715ACP | 57720ACP | — | — | — | — |
| A5 | 1 | FIGURE 577 RIGID GROOVED COUPLING | | — | — | 57730ACP | 57740ACP | 57760ACP | 57780ACP |
| A6 | 1 | GROOVE x THREADED OUTLET WELDED TEE | | 545004000 | 545004001 | — | — | — | — |
| A7 | 1 | SOLENOID VALVE NORMALLY CLOSED (SEPARATELY ORDERED) | | SEE TFP2180 | SEE TFP2180 | SEE TFP2180 | SEE TFP2180 | SEE TFP2180 | SEE TFP2180 |
| A8 | 1 | INVERTED FLARE SHUT-OFF VALVE* | | 545100100 | 545100100 | 545100099 | 545100100 | 545100100 | 545100100 |
| A9 | 1 | FLARE FITTING 90° 1/2" NPT x 1/2" TUBE | | 545100062 | 545100062 | 545100062 | 545100062 | 545100062 | 545100062 |
| A10 | 1 | TUBING ASSY, DIAPHRAGM CHAMBER SUPPLY | | 540000015 | 540000020 | 540000030 | 540000040 | 540000060 | 540000080 |

NOTES

a. Not VdS Approved

CH - Common Hardware - See Materials of Construction section for specifications.

FIGURE 6 (2 OF 2)
DV-5A VALVES
DOUBLE INTERLOCK PREACTION ELECTRIC/PNEUMATIC ACTUATION TRIM
EXPLODED VIEW

| Nominal Valve Size ANSI Inches (DN) | Inches (mm) | | | | | | | | |
|--|----------------|---------------|---------------|---------------|---------------|--------------|---------------|--------------|--------------|
| | A | B | C | D | E | F | G | H | J |
| 1 1/2 (40) | 2.8 (71) | 9.7 (246) | 10.4 (264) | 15.7 (399) | 16.8 (427) | 7.3 (185) | 10.2 (259) | 8.0 (203) | 1.2 (31) |
| 2 (50) | 2.8 (71) | 9.7 (246) | 10.4 (264) | 15.7 (399) | 16.8 (427) | 7.3 (185) | 10.2 (259) | 3.8 (97) | 2.9 (74) |
| 3 (80) | 3.0 (76) | 11.4 (290) | 12.0 (305) | 16.3 (414) | 18.6 (472) | 5.8 (147) | 13.8 (351) | 3.9 (99) | 3.6 (91) |
| 4 (100) | 3.0 (76) | 12.7 (323) | 13.1 (333) | 16.5 (419) | 21.0 (533) | 5.1 (129) | 16.8 (427) | 4.5 (114) | 4.3 (109) |
| 6 (150) | 4.5 (114) | 14.0 (356) | 15.0 (381) | 18.4 (467) | 24.8 (630) | 3.4 (86) | 22.4 (569) | 5.9 (150) | 5.7 (145) |
| 8 (200) | 5.3 (135) | 16.8 (427) | 17.2 (437) | 19.5 (495) | 29.1 (739) | 2.9 (74) | 27.5 (699) | 5.2 (132) | 6.7 (170) |

NOTES
1. Dimensions based on drain valves being open.
2. Dimensions do not provide installation clearance.




FIGURE 7
DV-5A VALVE
DOUBLE INTERLOCK PREACTION ELECTRIC/PNEUMATIC ACTUATION TRIM
NOMINAL DIMENSIONS

Valve Setting Procedure

Perform Steps 1 through 20 when initially setting the TYCO DV-5A Valve, after an operational test of the fire protection system, or after system operation due to a fire. See Figure 8.

Step 1. Close the System Main Control Valve (B).

Step 2. Close the Diaphragm Supply Valve (P) and Air Supply Valve (R).

Step 3. Open the Main Drain Valve (D), System Drain Valve (E), and all auxiliary drains in the system. Close the auxiliary drain valves and the System Drain Valve (E) after water ceases to discharge. Leave the Main Drain Valve (D) open.

At this time make certain that the Pressure Gauge Valves and the Alarm Control Valve (H), as applicable, are open.

NOTICE

Do not open the Inspector's Test Connection and auxiliary drains if resetting after a system test; otherwise, system air pressure will be relieved unnecessarily.

Step 4. Depress the plunger of the Automatic Drain Valve (F) to verify that it is open.

Step 5. Clean the Diaphragm Supply Strainer (Q) by removing the clean-out plug and strainer basket. The Diaphragm Supply Strainer (Q) may be flushed out by momentarily opening the Diaphragm Supply Valve (P).

Step 6. Inspect for and clear all ice plugs where system piping has been exposed to freezing conditions and when there has been a flow of water into the system.

Step 7. Replace all damaged or operated sprinklers. Replacement sprinklers must be of the same type and temperature rating as those that operated.

NOTICE

In order to prevent the possibility of a subsequent operation of an overheated solder type sprinkler, any solder type sprinklers possibly exposed to a temperature greater than their maximum rated ambient must also be replaced.

Step 8. Service the air dryer, if applicable, in accordance with the manufacturer's instructions.

Step 9. De-energize the Solenoid Valve (V) by resetting the electric detection system in accordance with the manufacturer's instructions.

Step 10. Operate (open) the Manual Control Station (M) and then open the Diaphragm Supply Valve (P). After unaerated water ceases to discharge from the Manual Control Station (M) drain tube, slowly close the operating lever by pushing it up. Do not close the hinged cover at this time.

Step 11. After allowing water to flow out of the Manual Reset Actuator (N) drain tube until aerated water ceases to discharge, reset the Manual Reset Actuator (N) by pressing the Reset Knob and hold until water stops flowing from its drain tube and the pressure builds and reaches approximately 15 psi (1,0 bar) on the Diaphragm Gauge (K). Pressure will then build up in the DV-5A Diaphragm Chamber.

Step 12. Inspect the actuation device drain connections. Any leaks must be corrected before proceeding to the next step. Electric/Pneumatic Actuation drain connection to be inspected are from the Manual Control Station (M) and Dry Pilot Actuator (W) shown in Figure 4.

Step 13. Verify the ability for the DV-5A Diaphragm to hold pressure as follows:

- With the diaphragm chamber pressurized per Step 11, temporarily close the Diaphragm Supply Valve (P), and then observe the Diaphragm Gauge (K) for a drop in pressure.
- If a drop in pressure is noted, the DV-5A Diaphragm is to be replaced and/or any leaks must be corrected before proceeding to the next step.
- If the Diaphragm Gauge (K) indicates no drop in pressure, re-open the Diaphragm Supply Valve (P) and proceed to the next step.

Step 14. Open the Air Supply Valve (S) and allow the system to automatically re-establish its nominal system air pressure. Observe the Automatic Drain Valve (F) for leaks. If there are leaks, determine/correct the cause of the leakage problem.

- Nominal system air pressure for Electric/Electric Actuation is typically 15 psi (1,0 bar).
- Nominal system air pressure for Electric/Pneumatic Actuation is per Graph B.

Step 15. Open the System Shut-Off Valve (X), as will be the case when resetting a system after performing an operational test.

Step 16. Partially open the System Main Control Valve (B). Slowly close the Main Drain Valve (D) as soon as water discharges from the Main Drain Valve (D). Observe the Automatic Drain Valve (F) for leaks. If there are leaks, determine/correct the cause of the leakage problem before proceeding.

NOTICE


When the System Main Control Valve (B) is partially opened, the pressure on the DV-5A Diaphragm Chamber may increase. This increase in pressure is normal, and if the pressure is greater than 300 psi (20,7 bar), the pressure is to be relieved by partially and temporarily opening the Manual Control Station (M); however, do not allow the pressure as indicated on the Diaphragm Gauge (K) to drop below the supply pressure shown on the Water Supply Gauge (J), since this action may result in tripping of the DV-5A Valve.

Step 17. Close the hinged cover on the Manual Control Station (M) and insert a new break rod in the small hole through the top of the enclosing box.

Step 18. Fully open the System Main Control Valve (B).

Step 19. After setting a fire protection system, notify the proper authorities and advise those responsible for monitoring proprietary and/or central station alarms.

| Item | Description | Item | Description | External Trim Connections | |
|------|--------------------------------|------|---|---------------------------|--|
| A | DV-5A Valve | N | Manual Reset Actuator | C1 | Diaphragm Supply Connection |
| B | System Main Control Valve | P | Diaphragm Supply Valve | C2 | Water Motor Alarm Connection |
| C | Waterflow Pressure Switch | Q | Diaphragm Supply Strainer | C3 | Air Supply Connection |
| D | Main Drain Valve | R | Inverted Flare Shut-Off Valve | C4 | Waterflow Pressure Alarm Switch Connection |
| E | System Drain Valve | S | Air Supply Valve | C5 | Low Air Pressure Switch Connection |
| F | Automatic Drain Valve | T | Air Pressure Relief Valve | C6 | Low Air Pressure Switch Connection |
| G | Alarm Test Valve | U | Low Air Pressure Alarm Switch | C7 | Main Drain Connection |
| H | Alarm Control Valve (Optional) | V | Solenoid Valve | | Drip Funnel Drain Connection |
| J | Water Supply Gauge | W | Dry Pilot Actuator | | |
| K | Diaphragm Gauge | X | System Shut-Off Valve (Shown in Figure 5) | | |
| L | System Gauge | | | | |
| M | Manual Control Station | | | | |



Notes:

- Port Connections P1 through P7 are described in Figure 2.

FIGURE 8
DV-5A DOUBLE INTERLOCK PREACTION VALVE ELECTRIC/PNEUMATIC ACTUATION
(Refer to Figures 6 for specific Bills of Materials)

Care and Maintenance

The following procedures and inspections must be performed as indicated, in addition to any specific requirements of the NFPA and any applicable standards recognized by the Approval agency. Any impairment must be immediately corrected. See Figure 8.

NOTICE

If the water supply needs to be shut off to the DV-5A valve and trim and cannot be shut off upstream of the system, close the System Main Control Valve (B), the Diaphragm Supply Valve (P), and the Water Supply Shut-Off Valve (R). This will allow any trim above the System Main Control Valve (B) to be taken apart for service if necessary.

The frequency at which the following procedures and inspections are to be performed are to be in accordance with the NFPA and any applicable specific requirements of the standards recognized by the Approval agency.

Before closing a fire protection system main control valve for maintenance work on the fire protection system that it controls, permission to shut down the affected fire protection systems must first be obtained from the proper authorities and all personnel who may be affected by this action must be notified.

The owner is responsible for the inspection, testing, and maintenance of their fire protection system and devices in compliance with this document, as well as with the NFPA and any applicable standards recognized by the Approval agency. Contact the installing contractor or product manufacturer with any questions.

Some procedures in this section result in the operation of the associated alarms. Notify the owner and the fire department, central station, or other signal station to which the alarms are connected before performing the tests.

It is recommended that automatic sprinkler systems be inspected, tested, and maintained by a qualified Inspection Service in accordance with the NFPA and any applicable standards recognized by the Approval agency.

It is recommended that the System Inspection Procedure be performed at least semi-annually by a qualified Inspection Service. The Double Interlock Preaction System Inspection Procedure may be followed in lieu of performing any of the operational tests recommended in the Technical Data Sheets for the 24 VDC Solenoid Valve, Dry Pilot Actuator, and Model MC-1 Manual Control Station.

It is recommended that the individuals responsible for the care and maintenance of the Double Interlock Preaction System develop a working understanding of the system, in general, prior to performing inspection and/or maintenance procedures. These instructions, as well as individual instructions for the solenoid valve, dry pilot actuator, manual control station, switches, and pressure maintenance device should be reviewed.

The following procedures pertain to the automatic control valve portion of the Double Interlock Preaction System. Refer to the manufacturer's instructions and NFPA 25 for care and maintenance procedures for all other devices (e.g., electric detection, main control and system shut-off valves, supervisory devices, sprinklers, etc.).

Before performing the System Inspection Procedure or Waterflow Alarm Test Procedure, which will result in operation of alarms, notify the proper authorities and all personnel who may be affected.

Drop in Water Supply Pressure Below Normal Range

NOTICE

If the water supply pressure is significantly reduced below the normally expected static pressure range (as could occur in the case of a water main break or repair), and there is a subsequent drop in the diaphragm chamber water pressure below its normal range (for example, due to a leak in a piping connection to or from the diaphragm chamber or, a leak in the diaphragm chamber check valve caused by dirt or debris in the check valve seal area), a deluge valve such as the DV-5A could inadvertently trip, if its water supply pressure is quickly restored.

A drop in the water supply pressure to below its normal range (as in the case of an interrupted water supply condition) constitutes an emergency impairment.

Should this condition occur, immediately close the System Main Control Valve (B) and use the following procedure to reset the system:

Step 1. Prior to the water supply pressure being restored to the closed System Main Control Valve (B), note the pressure indicated by the Diaphragm Gauge (K) and determine if the pressure is within the normally expected range.

Step 2. If the diaphragm chamber pressure is below the normal range, check for and correct any source of leakage from the diaphragm chamber prior to resetting the system.

Step 3. After the water supply pressure is restored to the System Main Control Valve (B), reset the DV-5A Valve in accordance with the Valve Setting Procedure section.

NOTICE

For fire protection systems subject to an emergency impairment caused by an interrupted water supply condition, it is recommended that consideration be given to installing a low water supply pressure switch with the appropriate alarm/indications to monitor the water supply pressure.

Waterflow Alarm Test Procedure

To test the waterflow alarm, open the Alarm Test Valve (G), which will allow a flow of water to the Waterflow Pressure Switch (C) and/or Water Motor Alarm. Upon satisfactory completion of the test, close the Alarm Test Valve (G).

To ensure drainage of the alarm line, depress the plunger on the Automatic Drain Valve (F).

**Electric/Pneumatic Actuation
System Operation Procedure**

Proper operation of the DV-5A Valve for both opening of the DV-5A Valve in a fire condition, or not opening the DV-5A Valve in a non-fire condition, must be verified as follows:

Step 1. Close the System Main Control Valve (B) and then open the Main Drain Valve (D).

Step 2. Manually operate the Releasing Panel and verify the following:

- The operation of the Releasing Panel and its associated alarms
- That there is no leakage from the Dry Pilot Actuator (W)

NOTICE

During this procedure, the Solenoid Valve (V) is opened; however, the Dry Pilot Actuator (W) should remain closed and the DV-5A Valve Diaphragm Chamber should remain pressurized.

This procedure is used to verify that the DV-5A Valve will remain set if the electric detection system operates but the sprinkler system remains in its normally pressurized condition.

Step 3. Open the Inspector's Test Connection but be prepared to close it immediately after verifying that the Low Air Pressure Alarm Switch (U) and its associated alarms operate properly. The Low Air Pressure Alarm Switch (U) should operate at the previously established pressure (see Installation section, Step 9).

Step 4. Close the Inspector's Test Connection.

Step 5. Close the System Shut-Off Valve (X) after the system air pressure has been restored to normal.

Step 6. Manually restore the electric fire detection system to a normal condition in accordance with the manufacturer's instructions. The Solenoid Valve (V) will then be de-energized and returned to its normally closed position.

Step 7. Open the System Main Control Valve (B) one turn beyond the position at which water just begins to flow from the Main Drain Valve (D).

Step 8. Close the Main Drain Valve (D).

Step 9. Close the Air Supply Valve (S).

Step 10. Open the Dry Pilot Actuator (W) by partially opening the System Drain Valve (E) to relieve air pressure at the inlet to the Dry Pilot Actuator (W). Verify that there is no leakage from the Dry Pilot Actuator (W).

NOTICE

During this procedure, the Dry Pilot Actuator (W) is opened; however, the Solenoid Valve (V) should remain closed and the DV-5A Valve Diaphragm Chamber should remain pressurized.

This procedure is used to verify that the DV-5A Valve will remain set if the Dry Pilot Actuator (W) operates due to loss of system air pressure and the electric detection system remains in a normal condition.

Step 11. Open (energize) the Solenoid Valve by operating the Releasing Panel and verify the following:

- That the DV-5A Valve operates as is indicated by a discharge of water from the System Drain Valve (E) and the Automatic Drain Valve (F). The Automatic Drain Valve (F) may or may not close depending on the flow past the partially open System Main Control Valve (B)
- That the Model MRA-1 Manual Reset Actuator (N) has operated as is indicated by water discharging into the Drip Funnel from the 1/2 in. drain tube connected to the Model MRA-1 Manual Reset Actuator (N)
- That the Waterflow Pressure Switch (C) and its associated alarms properly operate
- That the Water Motor Alarm, if applicable, properly operates

NOTICE

This procedure simulates opening of both the Dry Pilot Actuator (W) (loss of system air pressure) and Solenoid Valve (V) (operation of the Valve Releasing Panel) to verify automatic system operation.

Step 12. Reset the Double Interlock Preaction System in accordance with the Valve Setting Procedure section.

| Nominal Valve Sizes ANSI Inches (DN) | Torque lb-ft (N·m) | |
|---|--------------------------|-----------------|
| | Nuts | Short Hex Bolts |
| 1 1/2 (40) | 44 (59,7) | 35 (47,5) |
| 2 (50) | 44 (59,7) | 35 (47,5) |
| 3 (80) | 188 (254,9) | 150 (203,4) |
| 4 (100) | 396 (536,9) | 316 (428,4) |
| 6 (150) | 265 (359,3) | 212 (287,4) |
| 8 (200) | 545 (738,9) | 436 (591,1) |

TABLE B
DIAPHRAGM COVER BOLTS
MINIMUM TORQUE

Internal Valve Inspection

Once every five years during the annual operational test procedure and prior to the DV-5A Valve being reset and with the DV-5A Valve de-pressurized, the interior of the DV-5A Valve must be cleaned and inspected for wear and damage. Damaged or worn parts must be replaced. (Replacement of the Diaphragm every ten years is recommended, or more frequently if inspections and/or wear and tear warrant more frequent replacement.)

NOTICE

The Diaphragm Cover may be removed between Steps 4 and 5 of the resetting instructions, since at that point the DV-5A Valve should be de-pressurized as evident by a zero gauge reading on the Diaphragm Gauge (K) and Water Supply Gauge (J), as well as no water discharging from the Automatic Drain Valve (F).

To perform internal valve inspection between Steps 4 and 5 of the Valve Setting Procedure remove the Diaphragm cover as follows:

Step 1. Close the Inverted Flare Shut-Off Valve (R).

Step 2. Remove the Copper Tube Fitting between the Diaphragm Supply Valve (P) and the Inverted Flare Shut-Off Valve (R).

Step 3. Loosen the union securing the Electric/Pneumatic Actuation Trim and remove the Electric/Pneumatic Actuation Trim.

Step 4. Loosen and remove the union between the Diaphragm Cover and the MRA-1 Manual Reset Actuator (N) and remove the MRA-1 Manual Reset Actuator (N) subassembly.

Step 5. Remove the Diaphragm Valve Cover hardware, then slowly remove the Diaphragm Cover and perform internal valve inspection. Clean the valve interior and replace parts as necessary.

After cleaning and inspecting valve interior, and replacing parts as necessary, reinstall the Diaphragm Cover by completing the following steps to assure the Diaphragm Cover Fasteners are uniformly and securely tightened.

Step 1. With reference to Figure 1, ensure that the Diaphragm is properly oriented and that the proper hardware arrangement is utilized when assembling the Diaphragm Covers. The hardware arrangements differ depending on the size of the DV-5A Valve.

Step 2. By first using the Long Hex Bolts, support of the Diaphragm Cover will be provided before installing the Short Hex Bolts. Align Diaphragm in proper orientation with Valve Body, and then align Diaphragm Cover in proper orientation with Valve Body. Hand-tighten all fasteners.

Step 3. Using crossdraw sequence to assure uniformity, wrench-tighten Long Hex Bolts and Short Hex Bolts to appropriate torque values. Repeat crossdraw sequence two to three times at incremental torque values until reaching the torque values found in Table B.

Step 4. Inspect to assure all Hex Bolts are securely tightened.

Step 5. Using the union, secure the MRA-1 Manual Reset Actuator (N) to the Diaphragm Cover.

Step 6. Using the union, secure the Electric/Pneumatic Actuation Trim.

Step 7. Replace the Copper Tube Fitting between the Diaphragm Supply Valve (P) and the Inverted Flare Shut-Off Valve (R).

Step 8. Ensure that the unions and flare fittings are securely tightened.

Step 9. With the Diaphragm Supply Valve (P) closed, fully open the Inverted Flare Shut-Off Valve (R) stainless steel screw (approximately 1/2 in.) until resistance is met so as not to break the internal roll-pin. The internal roll-pin stops the removal of the Inverted Flare Shut-Off Valve (R) stainless steel screw.

Step 10. Proceed with Step 5 of the Valve Setting Procedures section in this data sheet.

NOTICE

If the water supply contains chemicals which tend to attack a polyester fabric-reinforced, EPDM rubber or the five year inspection indicates a build-up of debris within the DV-5A Valve that could affect its proper operation, then the frequency of the internal valve inspection procedure must be appropriately increased.

With reference to Figure 1, make certain that the Diaphragm is correctly oriented; otherwise, the DV-5A Valve cannot be properly set.

Under-tightening the Diaphragm Cover Bolts can result in internal and external leakage.

Use only TYCO replacement fasteners as specified in Figure 1.

Do not apply adhesives, lubricants, or other substances to the Diaphragm Valve Body.

Limited Warranty

For warranty terms and conditions, visit
www.tyco-fire.com.

Ordering Procedure

The TYCO DV-5A Automatic Water Control Valves may be ordered as follows:

Pre-Assembled Valves with Trim

DV-5A Valves with Galvanized Trim and Butterfly Valve

Specify: Size (specify), DV-5A Automatic Water Control Valve, G x G connections with assembled galvanized Americas Double Interlock Preaction Electric/Pneumatic Actuation Trim, complete with assembled Model BFV-300 Butterfly Valve, P/N (specify):

| | |
|------------------|-----------|
| 1 1/2 in. (DN40) | 551011415 |
| 2 in. (DN50) | 551011420 |
| 3 in. (DN80) | 551011430 |
| 4 in. (DN100) | 551011440 |
| 6 in. (DN150) | 551011460 |
| 8 in. (DN200) | 551011480 |

Notes:

Americas pressure switches, P/N 52-287-1-124 Solenoid Valve, and psi/kPa water pressure gauges are provided.

This arrangement is available for EMEA and APAC upon request. Contact your local distributor.

AMERICAS

DV-5A Valves with Galvanized Trim

Specify: Size (specify), DV-5A Automatic Water Control Valve, (specify) end connection with assembled galvanized Americas, Double Interlock Preaction Electric/Pneumatic Actuation Trim, P/N (specify):

| Grooved x Grooved | |
|-------------------|-----------|
| 1 1/2 in. (DN40) | 550011415 |
| 2 in. (DN50) | 550011420 |
| 3 in. (DN80) | 550011430 |
| 4 in. (DN100) | 550011440 |
| 6 in. (DN150) | 550011460 |
| 8 in. (DN200) | 550011480 |

| Flange x Flange ANSI | |
|----------------------|-----------|
| 3 in. (DN80) | 550021430 |
| 4 in. (DN100) | 550021440 |
| 6 in. (DN150) | 550021460 |
| 8 in. (DN200) | 550021480 |

| Flange x Grooved ANSI | |
|-----------------------|-----------|
| 3 in. (DN80) | 550031430 |
| 4 in. (DN100) | 550031440 |
| 6 in. (DN150) | 550031460 |
| 8 in. (DN200) | 550031480 |

| T x T NPT | |
|------------------|-----------|
| 1 1/2 in. (DN40) | 550061415 |
| 2 in. (DN50) | 550061420 |

Note: Pressure switches, P/N 52-287-1-124 solenoid valve, and psi/kPa water pressure gauges are provided.

Separate DV-5A Valves without Trim
See Table A for flange drilling specifications.

Specify: Size (specify), DV-5A Automatic Water Control Valve, (specify) end connection, P/N (specify):

| Groove x Groove | |
|------------------|-----------|
| 1 1/2 in. (DN40) | 530010015 |
| 2 in. (DN50) | 530010020 |
| 3 in. (DN80) | 530010030 |
| 4 in. (DN100) | 530010040 |
| 6 in. (DN150) | 530010060 |
| 8 in. (DN200) | 530010080 |

| Flange x Flange ANSI | |
|----------------------|-----------|
| 3 in. (DN80) | 530020030 |
| 4 in. (DN100) | 530020040 |
| 6 in. (DN150) | 530020060 |
| 8 in. (DN200) | 530020080 |

| Flange x Groove ANSI | |
|----------------------|-----------|
| 3 in. (DN80) | 530030030 |
| 4 in. (DN100) | 530030040 |
| 6 in. (DN150) | 530030060 |
| 8 in. (DN200) | 530030080 |

| T x T NPT | |
|------------------|-----------|
| 1 1/2 in. (DN40) | 530060015 |
| 2 in. (DN50) | 530060020 |

Notes:

Valves are typically provided with flange drilling per ANSI B16.1 (Class 125) or ISO (7005-2 PN16).

Upon request, valves can be provided with flange drilling per JIS B 2210 or AS 2129. In which case part numbers are not assigned.

DV-5A Valve Trim

Specify: Size (specify), finish (specify), Electric/Pneumatic Actuation Trim for DV-5A Automatic Water Control Valves used in Double Interlock Preaction Fire Protection System, P/N (specify):

| Galvanized | |
|------------------|-----------|
| 1 1/2 in. (DN40) | 540001420 |
| 2 in. (DN50) | 540001420 |
| 3 in. (DN80) | 540001430 |
| 4 in. (DN100) | 540001440 |
| 6 in. (DN150) | 540001460 |
| 8 in. (DN200) | 540001480 |

| Black | |
|------------------|-----------|
| 1 1/2 in. (DN40) | 542001420 |
| 2 in. (DN50) | 542001420 |
| 3 in. (DN80) | 542001430 |
| 4 in. (DN100) | 542001440 |
| 6 in. (DN150) | 542001460 |
| 8 in. (DN200) | 542001480 |

Note: Pressure switches and/or solenoid valves for electric actuation are separately ordered.

EMEA

DV-5A Valves with Galvanized Trim

Specify: Size (specify), DV-5A Automatic Water Control Valve, (specify) end connection with assembled galvanized EMEA, Double Interlock Preaction Electric/Pneumatic Actuation Trim, P/N (specify):

| Grooved x Grooved | |
|-------------------|-----------|
| 1 1/2 in. (DN40) | 550111415 |
| 2 in. (DN50) | 550111420 |
| 3 in. (DN80) | 550111430 |
| 4 in. (DN100) | 550111440 |
| 6 in. (DN150) | 550111460 |
| 8 in. (DN200) | 550111480 |

| Flange x Flange ANSI | |
|----------------------|-----------|
| 3 in. (DN80) | 550121430 |
| 4 in. (DN100) | 550121440 |
| 6 in. (DN150) | 550121460 |
| 8 in. (DN200) | 550121480 |

| Flange x Grooved ANSI | |
|-----------------------|-----------|
| 3 in. (DN80) | 550131430 |
| 4 in. (DN100) | 550131440 |
| 6 in. (DN150) | 550131460 |
| 8 in. (DN200) | 550131480 |

| Flange x Flange ISO | |
|---------------------|-----------|
| 3 in. (DN80) | 550141430 |
| 4 in. (DN100) | 550141440 |
| 6 in. (DN150) | 550141460 |
| 8 in. (DN200) | 550141480 |

| Flange x Grooved ISO | |
|----------------------|-----------|
| 3 in. (DN80) | 550151430 |
| 4 in. (DN100) | 550151440 |
| 6 in. (DN150) | 550151460 |
| 8 in. (DN200) | 550151480 |

| T x T ISO | |
|------------------|-----------|
| 1 1/2 in. (DN40) | 550171415 |
| 2 in. (DN50) | 550171420 |

Note: Pressure switches, P/N 52-287-1-124 solenoid valve, bar/psi water pressure gauges, and NPT to ISO threaded trim adaptors for external connections are provided.

Separate DV-5A Valves without Trim
See Table A for flange drilling specifications.

Specify: Size (specify), DV-5A Automatic Water Control Valve, (specify) end connection, P/N (specify):

| Groove x Groove | |
|------------------|-----------|
| 1 1/2 in. (DN40) | 530010015 |
| 2 in. (DN50) | 530010020 |
| 3 in. (DN80) | 530010030 |
| 4 in. (DN100) | 530010040 |
| 6 in. (DN150) | 530010060 |
| 8 in. (DN200) | 530010080 |

| Flange x Flange ANSI | |
|----------------------|-----------|
| 3 in. (DN80) | 530020030 |
| 4 in. (DN100) | 530020040 |
| 6 in. (DN150) | 530020060 |
| 8 in. (DN200) | 530020080 |

| Flange x Groove ANSI | |
|----------------------|-----------|
| 3 in. (DN80) | 530030030 |
| 4 in. (DN100) | 530030040 |
| 6 in. (DN150) | 530030060 |
| 8 in. (DN200) | 530030080 |

| T x T NPT | |
|------------------|-----------|
| 1 1/2 in. (DN40) | 530060015 |
| 2 in. (DN50) | 530060020 |

Flange x Flange ISO

| | |
|---------------|------------|
| 3 in. (DN80) | .530040030 |
| 4 in. (DN100) | .530040040 |
| 6 in. (DN150) | .530040060 |
| 8 in. (DN200) | .530040080 |

Flange x Groove ISO

| | |
|---------------|------------|
| 3 in. (DN80) | .530050030 |
| 4 in. (DN100) | .530050040 |
| 6 in. (DN150) | .530050060 |
| 8 in. (DN200) | .530050080 |

T x T ISO

| | |
|------------------|------------|
| 1 1/2 in. (DN40) | .530070015 |
| 2 in. (DN50) | .530070020 |

Notes:

Valves are typically provided with flange drilling per ANSI B16.1 (Class 125) or ISO (7005-2 PN16).

Upon request, valves can be provided with flange drilling per JIS B 2210 or AS 2129. In which case part numbers are not assigned.

DV-5A Valve Trim

Specify: Size (specify), finish (specify), Double Interlock Praction Electric/Pneumatic Actuation Trim for DV-5A Automatic Water Control Valves used in Deluge Fire Protection System, P/N (specify):

Galvanized

| | |
|------------------|------------|
| 1 1/2 in. (DN40) | .540101420 |
| 2 in. (DN50) | .540101420 |
| 3 in. (DN80) | .540101430 |
| 4 in. (DN100) | .540101440 |
| 6 in. (DN150) | .540101460 |
| 8 in. (DN200) | .540101480 |

Black

| | |
|------------------|------------|
| 1 1/2 in. (DN40) | .542101420 |
| 2 in. (DN50) | .542101420 |
| 3 in. (DN80) | .542101430 |
| 4 in. (DN100) | .542101440 |
| 6 in. (DN150) | .542101460 |
| 8 in. (DN200) | .542101480 |

Note: Pressure switches, solenoid valves for electric actuation, water pressure gauges, and BFV-300 Butterfly Valve are separately ordered. NPT to ISO threaded adaptors are provided for External Trim Connections (drains, pressure switches, water motor alarms, etc.).

APAC

DV-5A Valves with Galvanized Trim

Specify: Size (specify), DV-5A Automatic Water Control Valve, (specify) end connection with assembled galvanized APAC, Double Interlock Praction Electric/Pneumatic Actuation Trim, P/N (specify):

Grooved x Grooved

| | |
|------------------|------------|
| 1 1/2 in. (DN40) | .550011415 |
| 2 in. (DN50) | .550011420 |
| 3 in. (DN80) | .550011430 |
| 4 in. (DN100) | .550011440 |
| 6 in. (DN150) | .550011460 |
| 8 in. (DN200) | .550011480 |

Flange x Flange ANSI

| | |
|---------------|------------|
| 3 in. (DN80) | .550021430 |
| 4 in. (DN100) | .550021440 |
| 6 in. (DN150) | .550021460 |
| 8 in. (DN200) | .550021480 |

Flange x Grooved ANSI

| | |
|---------------|------------|
| 3 in. (DN80) | .550031430 |
| 4 in. (DN100) | .550031440 |
| 6 in. (DN150) | .550031460 |
| 8 in. (DN200) | .550031480 |

T x T NPT

| | |
|------------------|------------|
| 1 1/2 in. (DN40) | .550061415 |
| 2 in. (DN50) | .550061420 |

Flange x Flange ISO

| | |
|---------------|------------|
| 3 in. (DN80) | .550041430 |
| 4 in. (DN100) | .550041440 |
| 6 in. (DN150) | .550041460 |
| 8 in. (DN200) | .550041480 |

Flange x Grooved ISO

| | |
|---------------|------------|
| 3 in. (DN80) | .550051430 |
| 4 in. (DN100) | .550051440 |
| 6 in. (DN150) | .550051460 |
| 8 in. (DN200) | .550051480 |

Note: Pressure switches, P/N 52-287-1-124 solenoid valve, and psi/kPa water pressure gauges are provided.

Separate DV-5A Valves without Trim

See Table A for flange drilling specifications.

Specify: Size (specify), DV-5A Automatic Water Control Valve, (specify) end connection, P/N (specify):

Groove x Groove

| | |
|------------------|------------|
| 1 1/2 in. (DN40) | .530010015 |
| 2 in. (DN50) | .530010020 |
| 3 in. (DN80) | .530010030 |
| 4 in. (DN100) | .530010040 |
| 6 in. (DN150) | .530010060 |
| 8 in. (DN200) | .530010080 |

Flange x Flange ANSI

| | |
|---------------|------------|
| 3 in. (DN80) | .530020030 |
| 4 in. (DN100) | .530020040 |
| 6 in. (DN150) | .530020060 |
| 8 in. (DN200) | .530020080 |

Flange x Groove ANSI

| | |
|---------------|------------|
| 3 in. (DN80) | .530030030 |
| 4 in. (DN100) | .530030040 |
| 6 in. (DN150) | .530030060 |
| 8 in. (DN200) | .530020080 |

T x T NPT

| | |
|------------------|------------|
| 1 1/2 in. (DN40) | .530060015 |
| 2 in. (DN50) | .530060020 |

Flange x Flange ISO

| | |
|---------------|------------|
| 3 in. (DN80) | .530040030 |
| 4 in. (DN100) | .530040040 |
| 6 in. (DN150) | .530040060 |
| 8 in. (DN200) | .530040080 |

Flange x Groove ISO

| | |
|---------------|------------|
| 3 in. (DN80) | .530050030 |
| 4 in. (DN100) | .530050040 |
| 6 in. (DN150) | .530050060 |
| 8 in. (DN200) | .530050080 |

T x T ISO

| | |
|------------------|------------|
| 1 1/2 in. (DN40) | .530070015 |
| 2 in. (DN50) | .530070020 |

Notes:

Valves are typically provided with flange drilling per ANSI B16.1 (Class 125) or ISO (7005-2 PN16).

Upon request, valves can be provided with flange drilling per JIS B 2210 or AS 2129. In which case part numbers are not assigned.

DV-5A Valve Trim

Specify: Size (specify), finish (specify), Electric/Pneumatic Actuation Trim for DV-5A Automatic Water Control Valves used in Double Interlock Praction Fire Protection System, P/N (specify):

Galvanized

| | |
|------------------|------------|
| 1 1/2 in. (DN40) | .540001420 |
| 2 in. (DN50) | .540001420 |
| 3 in. (DN80) | .540001430 |
| 4 in. (DN100) | .540001440 |
| 6 in. (DN150) | .540001460 |
| 8 in. (DN200) | .540001480 |

Black

| | |
|------------------|------------|
| 1 1/2 in. (DN40) | .542001420 |
| 2 in. (DN50) | .542001420 |
| 3 in. (DN80) | .542001430 |
| 4 in. (DN100) | .542001440 |
| 6 in. (DN150) | .542001460 |
| 8 in. (DN200) | .542001480 |

DV-5A Valve Trim Accessories

(for separately ordered valve trim)

Specify: (Specify Accessory Description), P/N (specify):

| | |
|---|---------------------------------------|
| Waterflow Pressure Alarm Switch, Potter PS10-2 (America/APAC) | .25720 |
| Waterflow Pressure Alarm Switch PS10-1 (EMEA) | .0260 |
| Air Pressure Alarm Switch, Potter PS40-2 (America/APAC) | .25710 |
| Air Pressure Alarm Switch PS40-1 (EMEA) | .0262 |
| Model WMA-1 Water Motor Alarm (America/APAC) | .526301001P |
| Model WMA-1 Water Motor Alarm (EMEA) | .526301021R |
| Model AMD-1 Air Maintenance Device | .523242002 |
| Model AMD-2 Air Maintenance Device | .523262001 |
| Model AMD-3 Nitrogen Maintenance Device | .523282001 |
| Model MC-1 Manual Control Stations | .522892001 |
| Water Gauges with bar/psi | .025500013 |
| 600 psi Water Gauge psi/kPa (service pressure over 300 psi) | .923431004 |
| Solenoid Valve for Releasing Service | Refer to Technical Data Sheet TFP2108 |

DV-5A Valve Replacement Parts

Specify: (Description) for use with (specify size) DV-5A Automatic Water Control Valve, P/N (see Figure 1)

DV-5A Valve Trim Replacement Parts

Specify: (Description) for use with DV-5A Valve Trim, P/N (see Figure 6)

SECTION

3

General Air Products Manual

Riser and Tank Mounted Oilless Air Compressors Installation, Operation and Maintenance Manual



OL *Plus* **& OLT *Plus* Series**

Riser and Tank Mounted Oilless Air Compressors
**Installation, Operation and
Maintenance Manual**



Call **1-800-345-8207**
or visit our web site for our complete product listing
www.GeneralAirProducts.com

version 2.3
07-2019

Table of Contents

Section 1 - Safety & Warnings

- 1.1 - Safety Guidelines
- 1.2 - General Information
- 1.3 - General Safety Information
- 1.4 - Safety Notes

Section 2 - Receiving

Section 3 - Installation Location

Section 4 - Mounting

Section 5 - Lubrication

Section 6 - Piping

- 6.1 - Piping Instructions
- 6.2 - OL Plus Series Riser Mounted Oilless Air Compressor Installation Drawing
- 6.3 - OLT Plus Series Tank Mounted Oilless Air Compressor Installation Drawing

Section 7 - Wiring

- 7.1 - Wiring Instructions
- 7.2 - Oilless Air Compressor Single & 3 Phase Wiring Drawing

Section 8 - Maintenance Instructions

Section 9 - Troubleshooting Guide

Section 10 - Warranty Policy

If there are any questions regarding installation, operation, or maintenance of this compressor, please call 800-345-8207

**IMPORTANT: ALL INFORMATION SUBJECT TO CHANGE WITHOUT NOTICE.
Consult factory for the most up to date version of this manual - 1-800-345-8207.**

Section 1 - Safety & Warnings

1.1 Safety Guidelines

This manual contains information that is very important to know and understand. This information is provided for SAFETY and to PREVENT EQUIPMENT PROBLEMS. To help recognize this information, observe the following symbols.



- Danger indicates an imminently hazardous situation which, if not avoided, **WILL** result in death or serious injury.



- Warning indicates a potentially hazardous situation which, if not avoided **COULD** result in death or serious injury.



- Caution indicates a potentially hazardous situation which, if not avoided, **MAY** result in minor or moderate injury.



- Notice indicates important information, that if not followed may cause damage to equipment.

1.2 General Information

This compressor is intended for installation indoors for use on dry sprinkler systems in accordance with the Standard for Installation of Sprinkler Systems, NFPA 13 and the National Electrical Code, NFPA 70. The compressor should be sized to restore and maintain the air pressure in the sprinkler system in accordance with the requirements in NFPA 13.

1.3 General Safety Information

1. Read all manuals included with this product carefully. Be thoroughly familiar with the controls and the proper use of the equipment.
2. Follow all local electrical and safety codes as well as National Electrical Codes (NEC), Occupational Safety and Health Act (OSHA), and National Fire Protection Association (NFPA).
3. Only persons familiar with these rules of safe operation should be allowed to use the equipment.
4. Keep visitors away and NEVER allow children in the work area.
5. Wear safety glasses and use hearing protection when operating the unit.
6. Do not stand on or use the unit as a handhold.
7. **Periodic inspection and test of this equipment is required.** Consult your installer and local codes to meet all requirements.
8. Check all fasteners at frequent intervals for proper tightness.

1.4 Safety Notes



- This compressor is not equipped and should NOT be used “as is” to supply breathing quality air.



- Motors, electrical equipment and controls can cause electrical arcs that will ignite flammable gas or vapor. Never operate or repair in or near flammable gas or vapor. Never store flammable liquids or gasses near the compressor.



- These compressors are suitable for pumping only atmospheric air. As defined in Compressed Gas Association Pamphlet G-7, page 3, atmospheric air is a mixture of elements and compounds where nitrogen and oxygen comprise more than 99% with all other trace gasses comprising less than 1%. **Do not use this compressor in contaminated environments or for pumping mixtures other than atmospheric air.**



- Compressed air contains liquid water and is saturated with water vapor, which can freeze when surrounding temperatures are lower than 32°F (0°C). Component selection to minimize the effects of water vapor must be considered.

Section 2 - Receiving

Your compressor is inspected at the factory and packaged to protect against shipping damage. When the compressor is unpacked, inspect for damage or missing parts. All claims should be settled directly with the freight company.



- Do not operate this compressor if damaged during shipment, handling or use. Any damage may result in failure and cause injury or property damage.

Section 3 - Installation Location

Locate the compressor in a clean, well ventilated area where air is relatively cool, clean and dry. A 110°F (43°C) maximum and 40°F (4.5°C) minimum temperature for surrounding and inlet air are recommended. Provide at least 12 to 18 inches of clearance from any wall or other obstruction that will interfere with airflow over and through the compressor. Blocking airflow through the fan may cause the compressor to overheat. Do not place the compressor in an area of excessive heat, such as near a boiler.

Section 4 - Mounting

OL Plus Series (Riser mounted units) may be mounted to a firm level floor, wall or system riser. A mounting bracket and straps are provided. Tank mounted units must be leveled and anchored to the floor; the vibration isolators (P/N KVP4X4) supplied with the unit must be used. Both tank and riser mounted units are shipped with a flex hose and union. The flex hose (P/N P3002MP) is recommended to be installed between the compressor or tank outlet and service piping.

Section 5 - Lubrication



- This compressor is designed for non-lubricated service. Bearings are permanently lubricated. **Do not lubricate any part of the compressor or motor.**

Section 6 - Piping

6.1 Piping Instructions



- Compressed air contains liquid water and is saturated with water vapor, which can freeze when surrounding temperatures are lower than 32°F (0°C). Component selection to minimize the effects of water vapor must be considered.

Piping between the compressor, accessory items and the sprinkler system must be at least ½" internal diameter to minimize pressure drop from the compressor to system. Larger pipe size may be required by code and may be substituted with no adverse effects.



- Smaller line size must not be used and will restrict the compressor flow, lowering capacity and causing the compressor/motor to work harder, which shortens compressor/motor life. All piping connected to the compressor must be fully supported and not transfer any loads to the compressor.

If an AMD-1 is used, allow sufficient distance between the compressor and AMD-1 to ensure that the maximum temperature at the AMD-1 is 200°F or less.



- When an AMD is used with riser mounted units, a riser mounted tank kit (P/N OLR-TK) is recommended to prevent short cycling the compressor.

All oilless compressors include a relief valve. For riser mounted models, the relief valve is installed on the compressor. For tank mounted models, an ASME Code relief valve is mounted on the compressor tank. This valve will open at a preset value above the pressure switch setting to prevent excess tank pressure in the event of a switch failure.



- Do not attempt to change the safety relief valve setting.

A manual drain is provided on the bottom of each tank mounted compressor. Moisture accumulated in the tank must be drained weekly. An automatic drain, P/N DVA-2T, is recommended in areas of high humidity.

The compressor outlet piping should contain an accessible drain. As a minimum a manual drain may be used, but an automatic drain is recommended to remove excess water.




- Accumulation of condensed water in the system can cause corrosion of components and reduction of system capacity.



- Warranty is void if a separate check valve is not installed to prevent water backflow to compressor.


Section 6 - Piping

6.2 OL Plus Series Riser Mounted Oilless Air Compressor Installation Drawing



Section 6 - Piping

6.3 OLT Plus Series Tank Mounted Oilless Air Compressor Installation Drawing



Section 7 - Wiring

7.1 Wiring Instructions



- Wiring should be in accordance with the national electrical code and any local codes or regulations. Have a licensed and competent electrician ensure that the voltage supplied matches the compressor voltage.



- Inadequate wiring size can cause insufficient voltage at the compressor during start-up. Overheating and damage can result to the motor and controls.



- Failure to use the pressure switch may result in overpressure of the compressor or other components in the system. Overpressure of the compressor can result in blown head gaskets or other damage.



- Grounding Instructions: This product must be connected to a grounded, metallic, permanent wiring system, or an equipment grounding terminal or lead on the product.

The supply wire must be of adequate size and no other equipment should be connected to the same line. The adjacent table lists the recommended wire size for each model based on a 100' run and lowest operating voltage. Consult factory for longer runs. The motors supplied are multiple voltage motors. A label on the pressure switch cover indicates the voltage the motor is pre-wired for. If the supply voltage, on site, is different from the voltage indicated on this label, change the internal motor voltage connections to match the supply voltage. To change internal voltage connections, remove the cover plate located on the rear or side of the motor and reconnect the wire leads as shown on the motor's wiring diagram.

On all three phase compressors an arrow on the motor indicates the required direction of rotation of the compressor. If the compressor rotates in the opposite direction, reverse the rotation of the motor. Interchanging any two incoming supply wires reverses rotation of three phase motors.

| Minimum Recommended Wire Size | | |
|-------------------------------|---------|---------|
| Model # | 1 Phase | 3 Phase |
| OL(T)12516** | 12 | N/A |
| OL(T)25033** | 12 | N/A |
| OL(T)36550** | 12 | 12 |
| OL(T)43075** | 10 | 12 |
| OL(T)615100** | 6 | 12 |
| OL(T)915150** | 6 | 12 |
| OL(T)1225200** | 10 | 10 |
| OL(T)32016**-LP | 12 | N/A |
| OL(T)55033**-LP | 12 | N/A |
| OL(T)86050**-LP | 12 | 12 |
| OL(T)99075**-LP | 10 | 12 |



- Single-phase motors include internal thermal overload protection, which has an automatic reset device.



- Disconnect electrical power before servicing to disable reset devices. Thermal protection can automatically start the motor when the protector resets.

On single phase models, the motor is pre-wired to the pressure switch provided, which controls starting (cut in pressure) and stopping (cut out pressure) of the motor. The pressure switch is factory set. Standard models switch is set at 27 to 30 psig cut in and 40 to 44 psig cut out. Low pressure models ("-LP") switch is set at 13 psig cut in and 18 psig cut out. Consult General Air Products before adjusting the pressure switch.


On three-phase compressors, the motor is not pre-wired to the pressure switch. Refer to the three phase wiring instruction drawing for recommended wiring. **A motor starter is required, for all three phase models, to protect the motor from overload conditions to meet NEC, NFPA70, Article 430. A motor starter is recommended, for all single phase models.** Consult the National Electric Code and local codes for motor starter requirements. Refer to the proper wiring instruction drawing for recommended wiring to a starter.




- Do not run two phases of a three phase supply through the pressure switch. Serious damage can result. Warranty is voided if connected this way.

Section 7 - Wiring


Convert Pressure Switch from 115V to 230V



1. Identification of wires.



2. Remove line contact jumper and HOT wire placeholder.



3. Remove motor contact jumper, leaving motor HOT in terminal. Retighten motor HOT wire in terminal.



4. Remove yellow wire nut from motor NEUTRAL.




5. Crimp a spade connector onto NEUTRAL wire.



6. Insert spade connector into other motor terminal. Use wiring diagram on side of motor to wire it for 230V.
7. Wire supply line 1 and line 2 to line contacts of pressure switch.

Section 7 - Wiring

7.2 Oilless Air Compressor Single & 3 Phase Wiring Drawing



Section 8 - Maintenance Instructions



WARNING

- Disconnect, tag, and lock out power source then release all pressure from the system before attempting to install, service, relocate, or perform any service.

The following instructions are based on normal operation. If the compressor is in an excessively dusty area, increase frequency of maintenance checks.

Weekly:

- Drain condensate from receiver and traps
- Check for unusual noise or vibration
- Clean air filters (only with non-petroleum based products)
- Clean all external parts of the compressor and motor

Monthly:

- Manually test safety relief valve
- Inspect air system for leaks
- Tighten fitting, nuts, and screws as required

Quarterly:

- Change filters

Warranty can be voided if modifications or adjustments are made without consultation and approval from factory personnel.

If there are any questions regarding installation, operation, or maintenance of this compressor, please call 800-345-8207

Section 9 - Troubleshooting Guide

| Symptom | Possible Cause(s) | Corrective Action |
|---|--|--|
| Motor hums and runs slowly or not at all. | 1. Low or no voltage 2. Shorted or open motor winding 3. Defective check valve 4. Defective pressure switch - contacts will not close | 1. Check voltage during start. Voltage must be within +/- 10% of nominal voltage to start motor. Increase wire size if necessary, to lower voltage drop. 2. Replace compressor 3. Replace check valve 4. Repair or replace pressure switch |
| Reset mechanism cuts out or fuses blow repeatedly | 1. Insufficient voltage to motor 2. Pressure switch set too high 3. Wrong fuse size 4. Piping too restrictive 5. Defective motor | 1. Check voltage during start. Voltage must be within +/- 10% of nominal voltage to start motor. Increase wire size if necessary, to lower voltage drop. 2. Consult factory, adjust or replace 3. Be sure fuses, heaters and/or overloads are properly rated or set 4. Add receiver vessel or increase pipe volume after compressor 5. Consult factory |
| Unit short cycles repeatedly | 1. Piping too restrictive 2. Air leaks | 1. Add receiver vessel or increase pipe volume after compressor 2. Repair leaks |
| Compressor overheating | 1. Dirty intake filter 2. Wrong motor rotation 3. Air flow to fan blocked | 1. Clean intake filter 2. Correct rotation 3. Clean air flow to fan or relocate unit |
| Excessive noise in operation | 1. Damaged bearings 2. Worn piston cup 3. Broken valves 4. Loose fan 5. Damaged fan guard | Contact General Air Products for technical support by calling 1-800-345-8207 |
| System pressure builds slowly | 1. Compressor sized incorrectly 2. Leaks or restrictions in piping 3. Dirty intake filter | 1. Check system size and compressor sizing 2. Correct leaks and remove restrictions 3. Clean intake filter |

Section 10 - Warranty Policy

GENERAL PROVISIONS & LIMITATIONS

General Air Products, Inc. (the "Company") warrants to each original purchaser ("Purchaser") of its new products from the Company or its Authorized Distributor that such products are, at the time of delivery to the Purchaser, made with good materials and workman- ship. No warranty is made with respect to:

1. Any product, which has been repaired or altered in such a way, in the Companies judgment, as to affect the product adversely.
2. Any product, which has, in the Companies judgment been subjected to negligence, accident, improper storage, improper installation or application.
3. Any product, which has not been operated or maintained in accordance with the recommendations of the Company.
4. Components or accessories manufactured, warranted and serviced by others.
5. Any reconditioned or prior owned product.

Claims for items described in 4. above should be submitted directly to the manufacturer.

WARRANTY PERIOD

The Company's obligation under this Warranty is limited to repair or, at its option, replacing during normal business hours at the designated facility of the Company, any part that in its judgment proved not to be as warranted within the applicable Warranty Period as follows.

COMPONENTS

All non-consumable components are warranted for 12 months from the date of purchase. Consumables are not covered under warranty. The unit must have been installed by either a factory authorized distributor or agent in accordance with the factory recommendations taking into account all other local site conditions not originally noted to the factory. The unit must be operated and maintained in accordance with the Factory recommendations and original design conditions. Failure to provide such proof of the above may void warranty.

LABOR TRANSPORTATION & INSPECTION

The Company will repair or replace any product or part thereof which in the Companies judgment is proved to be not as warranted. Labor costs are not covered under warranty.

All costs of transportation of product, labor or parts claimed not to be as warranted and, of repaired or replaced parts to or from factory shall be borne by purchaser. The Company may require the return of any part claimed not to be as warranted to one of its facilities as designated by the Company, transportation prepaid by Purchaser, to establish a claim under this warranty.

Replacement parts provided under the terms of the warranty are warranted for the remainder of the Warranty Period of the product upon which installed to the same extent as if such parts were original components.

DISCLAIMER

THE FOREGOING WARRANTY IS EXCLUSIVE AND IT IS EXPRESSLY AGREED THAT, EXCEPT AS TO TITLE, THE COMPANY MAKES NO OTHER WARRANTIES, EXPRESSED OR IMPLIED OR STATUTORY, INCLUDING ANY IMPLIED WARRANTY OR MERCHANTABILITY.

THE REMEDY PROVIDED UNDER THIS WARRANTY SHALL BE THE SOLE, EXCLUSIVE AND ONLY REMEDY AVAILABLE TO THE PURCHASER AND IN NO CASE SHALL THE COMPANY BE SUBJECT TO ANY OTHER OBLIGATIONS OR LIABILITIES. UNDER NO CIRCUMSTANCES SHALL THE COMPANY BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES, EXPENSES, LOSSES OR DELAYS HOWSOEVER CAUSED.

No statement, representation, agreement, or understanding, oral or written, made by any agent, distributor, representative or employee of the Company which is not contained in this Warranty will be binding upon the company unless made in writing and executed by an officer of the Company.

This warranty shall not be effective as to any claim which is not presented within 30 days after the date upon which the product is claimed not to have been as warranted. Any action for breach of this warranty must be commenced within one year after the date upon which the cause of action occurred.

Any adjustment made pursuant to this warranty shall not be construed as an admission by the Company that any product was not as warranted.

PROMPT DISPOSITION & RETURNS POLICY

The Company will make a good faith effort for prompt correction or other adjustment with respect to any product, which proves to be defective within the warranty period. Before returning any product, write or call the distributor, agent or authorized company from which the product was purchased, describing defect and giving date and number of original invoice, as well as proof of Factory supplied consumables and proof of scheduled maintenance. No products will be accepted for return without the Company issuing a "Returned Goods Authorization" (RGA) to the Purchaser and unless accompanied by a properly authorized RGA request form initiated by the Purchaser. Return freight must be prepaid and each returned product must have the RGA number clearly marked on the product. Title and risk of loss pass to buyer upon delivery to the common carrier.

PRODUCT SUITABILITY

Many States, Localities and Countries have codes and regulations governing sales, construction, installation, and/or use of products for certain purposes, which may vary from those in neighboring areas. While General Air Products, Inc. attempts to assure that its products comply with such codes, it cannot guarantee compliance, and cannot be responsible for how the product is installed or used? Before purchase and use of a product, please review the product application, and national and local codes and regulations, and be sure that the product, installation, and use will comply with them.

General Air Products, Inc.
118 Summit Drive
Exton, PA 19341
P: 610-524-8950
F: 610-524-8965

REV: 4/22/11

SECTION

4

United Fire Systems
UFS-710

NAMD-1
Instruction Sheet

INSTRUCTION SHEET

Nitrogen / Air Maintenance Device for Fire Sprinkler Systems
Model **NAMD-1**




Figure 1

DESCRIPTION

The **UNITED Fire Systems Model NAMD-1** is an FM Approved device for controlling the nitrogen and / or air pressure in preaction and dry-pipe fire sprinkler piping. The device is equipped with a high-precision pressure regulator capable of providing accurate regulation over a wide range of inlet pressures and gas flows. This is especially important for sprinkler corrosion inhibiting systems supplying nitrogen to the sprinkler system, since most nitrogen systems provide less gas flow than a conventional air compressor.

SPECIFICATIONS

| | |
|----------------------------------|-------------------------------------|
| Model No.: | NAMD-1 |
| Material (other than regulator): | Brass |
| Material (regulator body): | Zinc |
| Inlet: | 1/2" NPT Female |
| Outlet: | 1/2" NPT Female |
| Inlet Pressure Range: | 0-175 PSIG (0-1200 kPa gauge) |
| Outlet Pressure Range: | 15-60 PSIG (100-410 kPa gauge) |
| Maximum Pressure: | 175 PSIG (1200 kPa) |
| Temperature Range: | -30°F to +150°F (-34°C to +65°C) |
| Dimensions (approx.): | 9.75" L x 8.25" H (248 mm x 210 mm) |
| Weight (approx.): | 7 lbs. (3.2 kg) |

UNITED Fire Systems

Division of United Fire Protection Corporation
1 MARK ROAD
KENILWORTH, NJ 07033 USA
PHONE: 908-688-0300 FAX: 908-688-0218
unitedfiresystems.com

This document is provided for informational purposes only. UNITED Fire Systems assumes no responsibility for the product's suitability for a particular application. The product must be properly applied to perform as intended. The information in this document is believed to be correct at the time of publication. UNITED Fire Systems reserves the right to add to, delete, or revise any information in this document without notice.

INSTRUCTION SHEET

Nitrogen / Air Maintenance Device for Fire Sprinkler Systems
Model **NAMD-1**



1. INSTALLATION INSTRUCTIONS – READ AND UNDERSTAND BEFORE INSTALLATION

IMPORTANT



DO NOT disassemble the **Model NAMD-1** device!

- 1.1. Install the **Model NAMD-1** device in the nitrogen / air pressure supply line to the sprinkler valve trim.
- 1.2. **UNITED Fire Systems** highly recommends installing one (1) **Model NAMD-1** device for each sprinkler valve.
- 1.3. The device may be installed in any orientation.
- 1.4. Install the device as close as possible to the sprinkler valve receiving the pressure.
- 1.5. Locate the device in as a convenient place as possible, where the ball valves may be easily operated and the pressure gauge observed.
- 1.6. If the rigidity of the inlet and outlet piping is sufficient, no additional bracketing should be necessary. Otherwise, use standard split ring hangers and hardware to attach the device to the wall or other solid mounting location.

IMPORTANT



The **Model NAMD-1** device is designed to operate in one direction only. Refer to **Figure 1** to positively identify the **INLET** and **OUTLET** ports of the device.

- 1.7. Attach the piping from the pressure source to the **INLET** of the device. Piping shall be 1/2" nominal pipe size minimum. Use Teflon tape on the male pipe threads of the pipe only. DO NOT permit pipe thread sealant to enter the device.
- 1.8. Attach the piping from the **OUTLET** of the device to the proper connection point on the sprinkler valve trim. Piping shall be 1/2" nominal pipe size minimum. Use Teflon tape on the male threads of the pipe only. DO NOT permit pipe thread sealant to enter the device.
- 1.9. Proceed to the **COMMISSIONING** instructions below.

2. COMMISSIONING

- 2.1. Ensure all three (3) ball valves on the **Model NAMD-1** device are **CLOSED**.
- 2.2. Determine proper supervisory pressure for the sprinkler valve which the device is connected to.
- 2.3. Pull pressure regulator adjustment knob UP.
- 2.4. Turn pressure regulator adjustment knob COUNTERCLOCKWISE to remove all force from the regulating spring.
- 2.5. Apply nitrogen pressure from sprinkler corrosion inhibiting system to the device inlet.
- 2.6. Leak check the piping from the pressure source to the Model NAMD-1 device. Piping should be as leak-free as possible. Correct all leaks before proceeding.
- 2.7. Gradually open inlet shutoff valve. Pressure gauge on the device pressure regulator should indicate pressure.

IMPORTANT



When adjusting pressure regulator, always approach the desired adjustment from a LOWER to a HIGHER pressure.

- A. If pressure adjustment (as indicated on device pressure gauge) is LOW, turn pressure regulator adjustment knob CLOCKWISE to increase pressure to desired setting.
- B. If pressure adjustment (as indicated on the device pressure gauge) is HIGH, turn pressure regulator adjustment knob COUNTERCLOCKWISE to reduce pressure 3-5 PSIG below desired setting, then turn knob CLOCKWISE to increase pressure to desired setting.

UNITED Fire Systems

Division of United Fire Protection Corporation
1 MARK ROAD
KENILWORTH, NJ 07033 USA
PHONE: 908-688-0300 FAX: 908-688-0218
unitedfiresystems.com

This document is provided for informational purposes only. UNITED Fire Systems assumes no responsibility for the product's suitability for a particular application. The product must be properly applied to perform as intended. The information in this document is believed to be correct at the time of publication. UNITED Fire Systems reserves the right to add to, delete, or revise any information in this document without notice.

INSTRUCTION SHEET

Nitrogen / Air Maintenance Device for Fire Sprinkler Systems
Model **NAMD-1**



2. COMMISSIONING (continued)

- 2.8. Turn pressure regulator adjustment knob clockwise until pressure gauge indicates 2-3 PSIG above the desired supervisory pressure determined in step 2.2.
- 2.9. Gradually open outlet shutoff valve. Nitrogen pressure will reach the sprinkler valve trim.
- 2.10. Leak check the piping from the **Model NAMD-1** device to the sprinkler valve trim. Piping should be as leak-free as possible. Correct all leaks before proceeding.
- 2.11 Check that pressure gauge continues to indicate 2-3 PSIG above supervisory pressure. Adjust if necessary.
- 2.12. Push pressure regulator adjustment knob DOWN.

3. OPERATION

| Table 1 – Valve Positions | | | |
|-------------------------------------|------------------------|-------------------------|-----------------|
| MODE | INLET Shutoff Valve | OUTLET Shutoff Valve | BYPASS Valve |
| No Gas Supply To Sprinkler Valve | Closed | Closed | Closed |
| Initial-Fill With Air | Closed | Closed | OPEN |
| Supply System With Nitrogen | OPEN | OPEN | Closed |
| DO NOT Operate | OPEN | OPEN | OPEN |

4. INSPECTION AND MAINTENANCE

4.1 Monthly

- 4.1.1 Inspect the **Model NAMD-1** device valve position. Use Table 1 to verify that valve position is in accordance with desired MODE.
- 4.1.2 Inspect the pressure gauge. Verify that indicated pressure is 2-3 PSI above the desired supervisory pressure of the connected sprinkler valve. Refer to **2. COMMISSIONING** if regulator adjustment is required.

4.2 Annual At least annually, inspect and clean the device strainer screen.



Ensure that **Model NAMD-1** device is completely depressurized before inspecting and cleaning the strainer screen. Failure to do so can result in death or serious personal injury!



When ball valves have been CLOSED, the nitrogen / air supply is not available to pressurize the sprinkler system piping. Take required precautions to prevent inadvertent sprinkler valve operation. Notify applicable personnel of possible "low air" signals.

UNITED Fire Systems

Division of United Fire Protection Corporation
1 MARK ROAD
KENILWORTH, NJ 07033 USA
PHONE: 908-688-0300 FAX: 908-688-0218
unitedfiresystems.com

This document is provided for informational purposes only. UNITED Fire Systems assumes no responsibility for the product's suitability for a particular application. The product must be properly applied to perform as intended. The information in this document is believed to be correct at the time of publication. UNITED Fire Systems reserves the right to add to, delete, or revise any information in this document without notice.

INSTRUCTION SHEET

Nitrogen / Air Maintenance Device for Fire Sprinkler Systems
Model **NAMD-1**



4. INSPECTION AND MAINTENANCE (Continued)

4.2 Annual (Continued)

- 4.2.1 Ensure there is no pressure present in the **Model NAMD-1** device.
- 4.2.2 Hold device so that torque applied to strainer screen retainer does not move the device.
- 4.2.3 Refer to **Figure 1**. Apply suitable wrench to HEX on strainer screen retainer. Do NOT remove square plug.
- 4.2.4 Remove strainer screen retainer. Retain for replacement.
- 4.2.5 Examine rubber seal on strainer screen retainer. If damaged during removal, leakage may occur.
- 4.2.6 Remove strainer. Empty any loose material, and then flush with clean water. If necessary, use a wire brush to remove trapped particles. Dry strainer screen thoroughly before replacement.
- 4.2.7 If strainer screen is damaged, replace with new strainer screen UFS P/N 30-500003-401.
- 4.2.8 Insert strainer screen.
- 4.2.9 Replace strainer screen retainer, tightening wrench-tight.
- 4.2.10 See 2. COMMISSIONING to return Model NAMD-1 device to service.
- 4.2.11 Leak check the strainer screen retainer / strainer body connection. Correct leak if necessary.

UNITED Fire Systems

Division of United Fire Protection Corporation
1 MARK ROAD
KENILWORTH, NJ 07033 USA
PHONE: 908-688-0300 FAX: 908-688-0218
unitedfiresystems.com

This document is provided for informational purposes only. UNITED Fire Systems assumes no responsibility for the product's suitability for a particular application. The product must be properly applied to perform as intended. The information in this document is believed to be correct at the time of publication. UNITED Fire Systems reserves the right to add to, delete, or revise any information in this document without notice.